

my Secure Network Device File Access Server mySND-120



User Manual

Manufacturer: SEH Computertechnik GmbH Suedring 11 33647 Bielefeld Germany Phone: +49 (0)521 94226-29 Fax: +49 (0)521 94226-99 Support: +49 (0)521 94226-44 Email: info@seh.de Web: http://www.seh.de



Scan this QR code (meCard) using your smart phone.

Document: Type: User Manual Title: my Secure Network Device Version: 1.0

Online Links to Important Websites:

Support Contacts & Information: Sales Contacts & Information: Downloads: http://www.seh-technology.com/support http://www.seh-technology.com/sales http://www.seh-technology.com/services/ downloads/mySND.html

InterCon is a registered trademark of SEH Computertechnik GmbH.

SEH Computertechnik GmbH has endeavored to ensure that the information in this documentation is correct. If you detect any inaccuracies please inform us at the address indicated above. SEH Computertechnik GmbH will not accept any liability for any error or omission. The information in this manual is subject to change without notification.

All rights are reserved. Copying, other reproduction, or translation without the prior written consent from SEH Computertechnik GmbH is prohibited.

© 2013 SEH Computertechnik GmbH

All trademarks, registered trademarks, logos and product names are property of their respective owners.

Table of Contents

1 General Information	5
1.1 mySND	6
1.2 Documentation	7
1.3 Support and Service	9
1.4 Your Safety	10
1.5 First Steps	
1.6 Saving the IP Address in the SND Server	12
2 Administration Methods	16
2.1 Administration via the mySND Control Center	17
2.2 Administration via the InterCon-NetTool	
2.3 Administration via Email	
2.4 Administration via the Reset Button of the Device	24
3 Network Settings	25
3.1 How to Configure IPv4 Parameters	
3.2 How to Configure IPv6 Parameters	
3.3 How to Configure the DNS	
3.4 How to Configure SNMP	
3.5 How to Configure POP3 and SMTP	
3.6 How to Configure Bonjour	36
4 Device Settings	38
4.1 How to Determine a Description	
4.2 How to Configure the Device Time	
4.3 How to Use the Notification Service	
5 Media Management and Access Settings	42
5.1 How to Manage User Accounts (Access Control)	
5.2 How to Prepare Removable Media	
5.3 How to Configure the Media assignment	48
5.4 How to Configure File Filters	
5.5 How to Configure the Automatic File Transfer	53

6 Working with the mySND File Browser	57
6.1 How to Use the mySND File Browser	
6.2 How to Display Files in the mySND File Browser	60
6.3 How to Select Files	61
6.4 How to Sort Files	
6.5 How to Search Files	
6.6 How to Store Files on a Client	64
6.7 How to Email Files via the mySND File Browser	
6.8 How to Rename Files	
6.9 How to Delete Files	66
7 Security	68
7.1 How to Define the Encryption Level for SSL/TLS Connections	
7.2 How to Control the Access to the mySND File Browser and	
the mySND Control Center	70
7.3 How to Manage Sessions	72
7.4 How to Enable/Disable the USB Port	73
7.5 How to Control the Access to the SND Server	
(TCP Port Access Control)	
7.6 How to Use Certificates Correctly	
7.7 How to Use Authentication Methods	84
8 Maintenance	
8.1 How to Secure the SND Parameters (Backup)	
8.2 How to Reset the SND Parameters to their Default Values	
8.3 How to Perform an Update	
8.4 How to Restart the SND Server	
0 Appendix	00
9 Appendix	
9.1 Glossary	
9.2 Parameter List	
9.3 Troubleshooting.	
9.4 List of Figures.	
9.5 Index	123

1 General Information This chapter contains information concerning the device and the documentation as well as notes about your safety. You will learn how to benefit from your SND Server and how to operate the device properly. What information do 'mySND' ⇔≧6 • you need? 'Documentation' ⇔🖹7 • 'Support and Service' ⇒ 🖹 9 ٠ • 'Your Safety' ⇔ 🖹 10 • 'First Steps' ⇔≣11

1.1 mySND

Purpose mySND (my Secure Network Device) is used to safely deploy files within the network. Files from a non-network-enabled SD card and a non-network-enabled USB mass storage device (e.g. USB stick, hard drive, etc.) can be made available to several network participants. To do this, the SD card is inserted into the integrated network-enabled SD card reader. Alternatively, the USB mass storage device is connected to the USB port of the SND Server.

The file is accessed via the 'mySND File Browser'. The administration of the SND Server is done via the 'mySND Control Center'.

System SND Server have been designed for the use in TCP/IP-based networks.

The mySND File Browser and the mySND Control Center can only be used if your browser software accepts cookies and if JavaScript is enabled.

Supported browsers:

- Mozilla Firefox (version 3 or later)
- Google Chrome
- Internet Explorer (version 7 or later)
- Safari

A screen resolution of at least 1024 x 768 pixels is required.

Procedure and Basic Functions After embedding the SND Server into the network, you must configure the administrator account and additional user accounts. Access data, privileges and file filters are assigned to each account. The SD cards and user accounts are then linked to each other via media assignments.

After connecting a removable media, the users authenticate themselves in the mySND File Browser. The access to the files and the work with files (downloading files, sending files, etc.) depends on the assigned account properties and media assignments.


1.2 Documentation

Please note the following names in this documentation:

- SD card \rightarrow removable medium
- USB mass storage device \rightarrow removable media

Since the File Access Server mySND-120 provides the mySND feature, it is called SND Server.

Structure of the Documentation The mySND documentation consists of the following documents:



Document Features This documentation has been designed as an electronic document for screen use. Many programs (e.g. Adobe[®] Reader[®]) offer a bookmark navigation feature that allows you to view the entire document structure.

This document contains hyperlinks to the associated information units. If you want to print this documentation, we recommend using the printer setting 'Duplex' or 'Booklet'.

Terminology Used in
this DocumentThe explanation of technical terms used in this document is
summarized in a glossary. The glossary provides a quick overview of
technical matters and background information; see: ⇔≧99.

Symbols and Conventions

A variety of symbols are used within this document. Their meaning is listed in the following table:

Symbol / Convention	Description
Warning	A warning contains important information that must be heeded. Non-observance may lead to malfunctions.
Note	A notice contains information that should be heeded.
Proceed as follows:<i>Mark</i>	The 'hand' symbol marks the beginning of instructions. Individual instructions are set in italics.
🌣 Confirmation	The arrow confirms the consequence of an action.
☑ Requirements	Hooks mark requirements that must be met before you can begin the action.
D Option	A square marks procedures and options that you can choose.
•	Eye-catchers mark lists.
	This sign indicates the summary of a chapter.
⇒≞	The arrow marks a reference to a page within this document. In the PDF file, you can jump to this page by clicking the symbol.
Bold	Established terms (of buttons or menu items, for example) are set in bold.
Courier	Command lines are set in Courier font.
'Proper names'	Proper names are put in inverted commas

1.3 Support and Service

Support If questions remain, please contact our hotline. SEH Computertechnik GmbH offers extensive support.

V	Monday through Thursday Friday	from 8:00 a.m. to 4:45 p.m. and from 8:00 a.m. to 3:15 p.m. (CET)
	+49 (0)521 94226-44	
@	support@seh.de	

Current Services

The following services can be found on the homepage of SEH Computertechnik GmbH <u>http://www.seh-technology.com</u> :



- current firmware/software
- current tools
- current documentation
- current product information
- product data sheets
- and much more

1.4 Your Safety

Read and observe all safety regulations and warnings found in the documentation, on the device and on the packaging. This will avoid potential misuse and prevent damages to people and devices.

SEH Computertechnik GmbH will not accept any liability for personal injuries, property damages and consequential damages resulting from the non-observance of the mentioned safety regulations and warnings. SEH Computertechnik GmbH will not accept any liability for loss of data, property damages and consequential damages resulting from the non-observance of the mentioned safety regulations and warnings.

- Intended Use The SND Server is operated in TCP/IP networks. mySND is used for the secure deployment of data on non-network-enabled SD cards and USB mass storage devices for several network participants. The SND Server has been designed for use in office environments.
- **Improper Use** All uses of the device that do not comply with the mySND functionalities described in the documentation are regarded as improper uses. It is not allowed to make modifications to the hardware and software or to try to repair the device.
- **Safety Regulations** Before starting the initial operation procedure of the SND Server, please note the safety regulations in the 'Quick Installation Guide'. The Quick Installation Guide is enclosed in the packaging.

Warnings Read and observe all warnings mentioned in this document. Warnings are found before any instructions known to be dangerous. Warnings are found before any instructions known to be dangerous.

Warning!

Data Backup (Backup) To prevent data loss and/or data corruption on the respective removable medium and consequential damages, we strongly recommend you to make a backup copy of your data on a different storage medium before the initial operation, data access and data processing. Keep the storage medium with the backup copy in a safe place.

Disclaimer SEH Computertechnik GmbH will not be liable for loss of data and/or data corruption, consequential damages or data recovery.

1.5 First Steps

This section provides all the information that you need for a fast operational readiness.

- Proceed as follows:
- 1. Read and observe the security regulations in order to avoid damages to people and devices; see: ⇒ 🖹 10.
- 2. Carry out the hardware installation. The hardware installation comprises the connection of the SND Server to the network, removable media and the mains supply; see: 'Quick Installation Guide'.
- Make sure that an IP address is stored in the SND Server; see:
 ⇒
 ¹
 ¹
 ¹
 ²

- Configure the administrator account and additional user accounts; see: ⇒
 ¹ 42.
- 5. Create a media assignment for the SD cards; see: $\Rightarrow \textcircled{B}$ 48.
- 6. (Optional) Enable the USB port; see: $\Rightarrow \square 73$.
- 7. Authenticate yourself in the mySND File Browser; see: $\Rightarrow \blacksquare 57$.
- The access to the files and the work with files are possible.

1.6 Saving the IP Address in the SND Server

Why IP Addresses?

An IP address is used to address network devices in an IP network. TCP/IP network protocols require the storing of the IP address in the SND Server so that the device can be addressed within the network.

How Does the SND Server Obtain IP Addresses? The SND Server is able to assign itself an IP address during the initial installation. Boot protocols are used to assign an IP address automatically to the SND Server. Upon delivery, the boot protocols 'BOOTP' and 'DHCP' are enabled.

Once the SND Server is connected to the network, the SND Server checks whether an IP address can be obtained via the boot protocols BOOTP or DHCP. If this is not the case, the SND Server assigns itself an IP address from the address range (169.254.0.0/16) which is reserved for ZeroConf.

Once the SND Server has automatically received an IP address via a boot protocol, you can save a freely definable IP address in the SND Server. The assigned IP address of the SND Server can be determined and modified via the software tool 'InterCon-NetTool'; see: \Rightarrow 20.

Different methods for the assignment of the IP address are described in the following.

Automatic Methods of IP Address Assignments

- 'BOOTP' ⇒≞13
- 'DHCP' ⇒ 🖹 13
- 'Auto Configuration (IPv6 Standard)' ⇒
 ¹■14

Manual Methods of IP Address Assignments

- 'InterCon-NetTool' ⇒ 🖹 14
- 'ARP/PING' ⇒ 🖹 15

ZeroConf

If no IP address can be assigned via boot protocols, the SND Server assigns itself an IP address via ZeroConf. For this purpose, the SND Server picks an IP address at random from the address range (169.254.0.0/16) which is reserved for ZeroConf.

You can use the domain name service of Bonjour for the name resolution of the IP address; see: \Rightarrow \exists 36.

BOOTP

The SND Server supports BOOTP, which means that the IP address of the SND Server can be assigned via a BOOTP server.

Requirements \square The 'BOOTP' parameter has been enabled, see: $\Rightarrow \square 25$.

 \blacksquare A BOOTP server is available in the network.

If the SND Server is connected, it asks the BOOTP host for the IP address and the host name. The BOOTP host answers and sends a data packet containing the IP address. The IP address is saved in the SND Server.

DHCP

The SND Server supports DHCP, which means that the IP address of the SND Server can be assigned dynamically via a DHCP server.

Requirements \square The 'DHCP' parameter has been enabled, see: $\Rightarrow \square 25$.

 \blacksquare A DHCP server is available in the network.

After the hardware installation, the SND Server asks a DHCP server for an IP address by means of a broadcast query. The DHCP server identifies the SND Server on the basis of its hardware address and sends a data packet to the SND Server.

This data packet contains, among others, the IP address of the SND Server, the default gateway, and the IP address of the DNS server. The data is saved in the SND Server.

Auto Configuration (IPv6 Standard)

The SND Server can have an IPv4 address and several IPv6 addresses at the same time. The IPv6 standard is used to automatically assign IP addresses in IPv6 networks. When connected to an IPv6 network, the SND Server will automatically obtain an additional link-local IPv6 address.

The SND Server uses the link-local IP address to search for a router. The SND Server sends so-called 'Router Solicitations' (RS) to the special multicast address FF02::2. The available router will then return a 'Router Advertisement' (RA) containing the required information.

With a prefix from the range of the globally unique addresses, the SND Server can compose its own address. It simply replaces the first 64 bits (prefix FE80::) with the prefix that was sent in the RA.

Requirements \square The 'IPv6' parameter has been activated.

 \blacksquare The 'Automatic configuration' parameter has been activated.

To configure the assignment of IPv6 addresses, see: $\Rightarrow \blacksquare 28$.

InterCon-NetTool

The InterCon-NetTool has been developed by SEH Computertechnik GmbH for the administration of SEH network devices. The IP Wizard of the InterCon-NetTool helps you to configure the TCP/IP parameters, e.g. the IP address. You can manually enter the desired IPv4 address and save it in the SND Server using the IP Wizard. To configure an IPv4 address via the InterCon-NetTool, see: \Rightarrow \cong 26.

mySND Control Center

You can manually enter the desired IPv4 address and save it in the SND Server using the mySND Control Center IP Wizard.

- To configure an IPv4 address via the mySND Control Center, see:
 ⇒
 ¹ 25.
- To configure an IPv6 address via the mySND Control Center, see:
 ⇒
 ¹ ≥ 28.

ARP/PING

The assignment of the IP address to the hardware address can be done via the ARP table. The ARP table is an internal system file in which the assignment is temporarily saved (about 15 min). This table is administered by the ARP protocol.

By means of the 'arp' and 'ping' commands, you can save the IP address in the SND Server. If the SND Server already has an IP address, the 'arp' and 'ping' commands cannot be used to save a new IP address.

However, an IP address from the address range (169.254.0.0/16) which is reserved for ZeroConf can be overwritten by means of the 'arp' and 'ping' commands.

The 'arp' command is used for editing the ARP table. The 'ping' command sends a data packet containing the IP address to the hardware address of the SND Server. When receiving the data packet, the SND Server permanently saves its IP address.

The implementation of the 'arp' and 'ping' command depends on the system used. Read the documentation for your operating system.

Requirements \square The 'ARP/PING' parameter has been enabled, see: $\Rightarrow \square 25$.

Edit the ARP table:

<u>Syntax:</u> arp -s <IP address> <hardware address> <u>Example:</u> arp -s 192.168.0.123 00-c0-eb-00-01-ff

Assign a new IP address to the SND Server: <u>Syntax:</u>ping <IP address> <u>Example:</u>ping 192.168.0.123

2 Administration Methods You can administer and configure the SND Server in a number of ways. The following chapter gives you an overview of the various administration options. You will get information on when to use these methods and which functions these methods support. What information do • you need? 'Administration via the InterCon-NetTool' ⇔ [®]20 ٠ 'Administration via Email' ⇔≣22 ٠ 'Administration via the Reset Button of the Device' \Rightarrow 24 ۲

2.1 Administration via the mySND Control Center

Which Functions Are
Supported?The mySND Control Center comprises all features for the
administration and monitoring of the SND Server.

The mySND Control Center is stored in the SND Server and can be displayed by means of a browser software (Internet Explorer, Firefox, Safari).

The access to the mySND Control Center is controlled by means of user accounts (\Rightarrow 242). Users authenticate themselves via a user name and a password. Only users with administrator privilege have access to the mySND Control Center.

- **Start and Login** The login to the SND server is session-based. Up to 16 users can be logged on to the SND server at the same time. For further information; see: ⇔≧72.
- **Requirements** If The SND Server is connected to the network and the mains voltage.
 - \blacksquare The SND Server has a valid IP address.
 - \blacksquare The used user account has administrator privileges; see: \Rightarrow \blacksquare 42.

The user account 'Admin' and the password 'admin' have been configured by default. Change the password when you use the SND server in a real situation; see: $\Rightarrow \blacksquare 42$.

- Proceed as follows:
- 1. Open your browser.
- Enter the IP address of the SND Server as the URL. The login page appears. If the login page is not displayed, check the proxy settings of your browser.
- 3. Enter the user name and password of a user account.
- *4.* Click Login. The mySND File Browser will be displayed in the browser.
- 5. Click Control Center.

✤ The mySND Control Center will be displayed in the browser.

You can also start the mySND Control Center via the software tool 'InterCon-NetTool'.

- Proceed as follows:
- 1. Highlight the SND Server in the device list.
- 2. Select Actions Launch Browser from the menu bar. The login page appears.
- 3. Enter the user name and password of a user account.
- 4. Click Login. The mySND File Browser will be displayed.
- 5. Click Control Center.
- ↔ The mySND Control Center will be displayed in the browser.

http://10.168.1.15	51/backend/index_en.html			☆ ⊽ C	🔀 🔻 Google	<u>۶</u>
168.1.151 - ICODD4B0				Welco	me Admin @Logoul	t 🗆 File Browser
mySND C	ontrol Cei	nter				SEF
START	NETWORK	DEVICE	FILE BROWSER		SECURITY	MAINTENAN
	mySND-120 » Start					
			mySND-120 stat	us		
IC0DD4B0	General		Netw	ork		
	Default name	IC0DD4B0	IP add	lress	10.168.1.151	
	Host name		Subne	t mask	255.255.254.0	
	Serial number	27320130400013	Gatew	ay	10.168.0.223	
	Software	14.0.1	Remo	vable med	lia	
	Firmware	342.10	SD ca	rd	SD card_1	
	Description		USB d	evice	USB drive_1	
	Contact person		Eile B	rowser		
	Date/Time	2013-04-12 12:18:0			5	
			Media	ments	2	
			File fil	ters	3	

Fig. 1: Starting the mySND Control Center

Structure of the mySND Control Center The available menu items are located in the navigation bar (top). After selecting a menu item (simple mouse click), the available submenu items are displayed at the left. After selecting a submenu item, the corresponding page with its content is displayed (at the right).

Important information (IP address, host name, user account) is displayed at the top. The IP address allows you to directly go to the login page. The menu item File Browser allows you to go to the pane with the same name.

The manufacturer's contact details and additional information regarding the product are displayed under **Product & Company**. The **Sitemap** provides an overview of and direct access to all pages of the mySND Control Center.

You can choose your language by clicking the relevant flag.

All other menu items refer to the configuration of the SND Server. You will find a description of the menu items in the Online Help of the SND Server. To start the Online Help, click the ? icon.

- **Logout** Up to 16 users can be logged on to the SND server at the same time. If this number is reached, further logins will fail. Log off in order to allow other users to access the SND server.
 - 📴 Proceed as follows:
 - 1. Click Logout.
 - The login page appears. You have successfully logged out.

2.2 Administration via the InterCon-NetTool

The software InterCon-NetTool has been developed by SEH Computertechnik GmbH for the administration of SEH network devices (SND Server, TPG, print server, etc.). Depending on the network device you can configure various features via the InterCon-NetTool.

Mode of Operation After the InterCon-NetTool is started, the network will be scanned for connected network devices. The network range to be scanned is freely definable. All network devices found will be displayed in the 'device list'.

You can modify the device list and adapt it to your individual needs. You can mark and configure the devices in the device list.

Installation In order to use the InterCon-NetTool, the program must be installed on a computer with a Windows operating system. The installation file of the InterCon-NetTool can be found on the SEH Computertechnik GmbH homepage:

http://www.seh-technology.com/services/downloads/mySND.html

- Proceed as follows:
- 1. Start the InterCon-NetTool installation file.
- 2. Select the desired language.
- 3. Follow the installation routine.
- The InterCon-NetTool will be installed on your client.

Program StartTo start the program, double-click the InterCon-NetTool icon site.The icon is found on the desktop or the Windows start menu.
(Start \rightarrow Programs \rightarrow SEH Computertechnik GmbH \rightarrow InterCon-NetTool)

The settings of the InterCon-NetTool are saved in the 'InterCon-NetTool.ini' file. This file is stored in the user folder of the user that is currently logged in.

Structure of the InterCon-NetTool

After the program start you will see the main dialog with the following elements. The dialog may vary, depending on which elements you have chosen to be shown or hidden.

	Menu bar	Toolbar	Device	e list
	SN InterCon-NetTool		/	
	File Filter Actions Installation Search Extras He		_/	
	● AI ● ・ ● ・ ● ● <t< th=""><th>Address / Type 0.168.000.055 myUTN-50 0.168.001.150 myUTN-50 0.168.001.151 myVTN-80 0.168.001.167 myVTN-80 0.168.001.167 mySND-120 0.168.001.175 mySND-120 0.168.001.182 TPG-25 0.168.001.194 myUTN-150</th><th>Version Protocol 14.0.43 IP 14.0.43 IP Restart Default Settings Launch Browser IP Wizard 14.0.20 IP</th><th>NetWare Name IC0E6654 IC0D1F0B IC0D0480 IC0D04AC IC0D04AC IC0D04AC IC0D98AB IC00B65C 29</th></t<>	Address / Type 0.168.000.055 myUTN-50 0.168.001.150 myUTN-50 0.168.001.151 myVTN-80 0.168.001.167 myVTN-80 0.168.001.167 mySND-120 0.168.001.175 mySND-120 0.168.001.182 TPG-25 0.168.001.194 myUTN-150	Version Protocol 14.0.43 IP 14.0.43 IP Restart Default Settings Launch Browser IP Wizard 14.0.20 IP	NetWare Name IC0E6654 IC0D1F0B IC0D0480 IC0D04AC IC0D04AC IC0D04AC IC0D98AB IC00B65C 29
	Filter for the device list	Shortcut me	enu	
	Fig. 2: InterCon-NetTool - I	Main Dialog		
Which Functions Are Supported?	Using the InterCon-NetToo	ol, you can:		
sapported.	 'assign an IPv4 address 	to the SND Se	erver' ⇔≣26	

- 'switch from the BIOS mode to the default mode' \Rightarrow 119

Detailed information on how to use the InterCon-NetTool can be found in the Online Help. To start the Online Help, select Help – Online Help from the menu bar.

	2.3 Administration via Email
	You can administer the SND Server via email and thus via any computer with Internet access.
Functionalities	An email allows you to
	 send SND Server status information
	 define SND Server parameters or
	 perform an update on the SND Server.
Requirements	☑ A DNS server has been configured on the SND Server; see: ⇒ ¹ 30.
	☑ In order to receive emails, the SND Server must be set up as user with its own email address on a POP3 server.
	☑ POP3 and SMTP parameters have been configured on the SND Server; see: ⇒
Sending Instructions via Email	If you want to administer the SND Server, you must enter the relevant instructions into the subject line of your email.
Eman	📴 Proceed as follows:
	1. Open an email program.
	2. Write a new email.
	 Enter the SND Server address as recipient. Enter an instruction into the subject line; see: 'Syntax and
	Format of an Instruction' \Rightarrow 22.
	5. Send the email.
	The SND Server receives the email and carries out the instruction.
Syntax and Format of an Instruction	Note the following syntax for instructions in the subject line: cmd: <command/> [<comment>]</comment>

Commands	Option	Description
[<command/>]	get status	sends the status page of the SND Server
	get parameters	sends the parameter list of the SND Server
	set parameters	sends parameters to the SND Server. The syntax and values can be obtained from the parameter list, see: $rac{rac} \equiv 102$. Parameter and value must be entered into the email body; see: $rac{rac{rac}} \equiv 23$.
	update SND	Carries out an automatic update using the software that is attached to the mail.
	help	Sends a page with information about the administration via email.
[<comment>]</comment>		Freely definable text for descriptions.

The following commands are supported:

The following applies for the instructions:

- one or more space characters are allowed
- max. length is 128 byte
- only the ASCII format can be read

Security with TAN You will need a TAN for updates or parameter changes on the SND Server. You will get a current TAN from the SND Server via email, e.g. when receiving a status page. Enter the TAN into the first line of the email body. A space character must follow.

Parameter Changes Parameter changes are integrated into the email body with the following syntax:

<parameter> = <value>

The syntax and values can be obtained from the parameter list, see: $\Rightarrow \equiv 102$.

Example 1 This email causes the SND Server to send the parameter list to the sender of the email.




Fig. 3: Administration via Email - Example 1

Example 2 This email configures the parameter 'Description' on the SND Server.




Fig. 4: Administration via Email - Example 2

2.4 Administration via the Reset Button of the Device

LEDs, the reset button and various ports can be found on the SND Server. These components are described in the 'Quick Installation Guide'.

Using the reset button you can reset the SND Server's parameter values to their default setting; see: $\Rightarrow \blacksquare 93$.

3 Network Settings

=

You can define various settings for an ideal integration of the SND Server into a TCP/IP network. This chapter explains which network settings are supported by the SND Server.

What information do you need?

- 'How to Configure IPv4 Parameters' ⇔
 [●]25
- 'How to Configure the DNS' \Rightarrow $\exists 30$
- 'How to Configure SNMP' ⇒ ■31
- 'How to Configure POP3 and SMTP' ⇒ ■32
- 'How to Configure Bonjour' ⇒ 🖹 36

3.1 How to Configure IPv4 Parameters

TCP/IP (Transmission Control Protocol over Internet Protocol) forwards data packets across several connections and establishes a connection between the network participants.

The boot protocols DHCP and BOOTP belong to the TCP/IP protocol family. You can define various IPv4 parameters for an ideal integration of your SND Server into a TCP/IP network. For further information about the assignment of IP addresses, see: \Rightarrow 12.

What do you want to do?

□ 'Configuring IPv4 Parameters via the mySND Control Center' ⇒
[■]25

 \square 'Configuring IPv4 Parameters via the InterCon-NetTool' \Rightarrow 26

Configuring IPv4 Parameters via the mySND Control Center

- 彦 Proceed as follows:
- 1. Start the mySND Control Center.

- 2. Select NETWORK IPv4.
- *3.* Configure the IPv4 parameters; see: Table 2 \Rightarrow 26.
- 4. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

Table 2: IPv4 Parameters

Parameters	Description
DHCP BOOTP ARP/PING	Enables or disables the protocols DHCP, BOOTP, and ARP/PING. Protocols offer various possibilities to save the IP address in the SND Server. (See 'Saving the IP Address in the SND Server' ⇒ 12.) We recommend disabling these options once an IP address has been assigned to the SND Server.
IP address	IP address of the SND Server
Subnet mask	Subnet mask of the SND Server
Gateway	Gateway address of the SND Server

Configuring IPv4 Parameters via the InterCon-NetTool

Requirements	\blacksquare The InterCon-NetTool is installed on the client, see: \Rightarrow \blacksquare 20.
	The network scan via Multicast has been enabled in the InterCon-NetTool.
	\blacksquare The router in the network forwards multicast requests.
	📴 Proceed as follows:
	1. Start the InterCon-NetTool.
	 Highlight the SND Server in the device list. The SND Server is displayed in the device list under 'ZeroConf' with an IP address from the address range (169.254.0.0/16) which is reserved for ZeroConf.
	3. Select Installation – IP Wizard from the menu bar. The IP Wizard is started.
	4. Follow the instructions of the Wizard.
	😓 The settings will be saved.

M InterCon-NetTool					
File Filter Actions Installation Search Extr Wizard Printer Wizard Printer Wizard Printer Wizard	IP Address 169.254.126.032	Type ∠ mySND-120	Version 14.0.1	Protocol IP no reply	NetWare Name
• • • • • • • • • • • • • • • • • • •	Er	uter as gateway' i	s of the print serv s enabled the ad e this parameter if ess 010 mask 255	er, and the submet m dress of the multicast you want to edit the 	router found is used gateway manually. 151 000
			< Bad	k Next >	Cancel

Fig. 5: InterCon-NetTool - IP Wizard

3.2 How to Configure IPv6 Parameters

You can integrate the SND Server into an IPv6 network.

What are the Advantages of IPv6?	IPv6 (Internet Protocol version 6) is the successor of the more common IPv4. Both protocols are standards for the network layer of the OSI model and regulate the addressing and routing of data packets via a network. The introduction of IPv6 has many benefits:
	 IPv6 increases the IP address space from 2³² (IPv4) to 2¹²⁸ (IPv6) IP addresses.
	Auto Configuration and Renumbering
	 Efficiency increase during routing due to reduced header information.
	 Integrated services such as IPSec, QoS, Multicast
	Mobile IP
What is the Structure of an IPv6 Address?	An IPv6 address consists of 128 bits. The normal format of an IPv6 address is eight fields. Each field contains four hexadecimal digits representing 16 bits.
	Each field is separated by a colon (:). Example: fe80 : 0000 : 0000 : 0000 : 0000 : 10 : 10
	Leading zeros in a field can be omitted. <u>Example:</u> fe80 : 0 : 0 : 0 : 0 : 10 : 1000 : 1a4
	An IPv6 address may be entered or displayed using a shortened version when successive fields contain all zeros (0). In this case, two colons (::) are used. However, the use of two colons can be used only once in an address.
	<u>Example:</u> fe80 : : 10 : 1000 : 1a4
	As a URL in a Web browser, an IPv6 address must be enclosed in brackets. This prevents port numbers from being mistakenly regarded as part of an IPv6 address. <u>Example:</u> http://[2001:608:af:1::100]:443
	LAINPIC. MCCp://[2001:008:a1:1::100]:445

The URL will only be accepted by browsers that support IPv6.

Which Types of IPv6 Addresses are available? There are different types of IPv6 addresses. The prefixes of the IPv6 addresses provide information about the IPv6 address types.

- Unicast addresses can be routed globally. These addresses are unique and therefore unambiguous. A packet that is sent to a unicast address will only arrive to the interface that is assigned to this address. Unicast addresses have the prefixes '2' or '3'.
- Anycast addresses are assigned to more than one interface. This means that a data packet that is sent to this address will arrive at various devices. The syntax of anycast addresses is the same as the one of unicast addresses. The difference is that anycast addresses choose one interface out of many.
 A packet that is dedicated to an anycast address arrives at the nearest interface (in line with the router metrics). Anycast addresses are only used by routers.
- Multicast addresses allow you to send data packets to different interfaces at the same time without a proportional increase of the bandwidth. A multicast address can be recognized by the prefix 'ff'.
- 彦 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select NETWORK IPv6.
- 3. Configure the IPv6 parameters; see: Table 3 \Rightarrow 29.
- 4. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

Table 3: IPv6 Parameters

Parameters	Description
IPv6	Enables/disables the IPv6 functionality of the SND Server.

Parameters	Description
Automatic configuration	Enables/disables the automatic assignment of the IPv6 address for the SND Server.
IPv6 address	Defines a manually assigned IPv6 Unicast address in the n:n:n:n:n:n:n format for the SND Server. Every 'n' represents the hexadecimal value of one of the eight 16 bit elements of the address. An IPv6 address may be entered or displayed using a shortened version when successive fields contain all zeros (0). In this case, two colons (::) are used.
Router	Defines the IPv6 unicast address of the router. The SND Server sends its 'Router Solicitations' (RS) to this router.
Prefix length	Defines the length of the subnet prefix for the IPv6 address. The value 64 is preset. Address ranges are indicated by prefixes. The prefix length (number of bits used) is added to the IPv6 address and specified as a decimal number. The decimal number is separated by '/.

3.3 How to Configure the DNS

DNS is a service that translates domain names into IP addresses. Using DNS, names can be assigned to IP addresses and vice versa. If a DNS server is available in your network, you can use DNS for your SND Server.

If you use a domain name during the configuration process, you must first enable and configure DNS. DNS is used for the configuration of the time server, for example.

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select NETWORK DNS.
- 3. Configure the DNS parameters; see: Table 4 \Rightarrow 31.
- 4. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

Table 4: DNS Parameters

Parameters	Description
DNS	Enables/disables the name resolution via a DNS server.
Primary DNS server	Defines the IP address of the primary DNS server.
Secondary DNS server	Defines the IP address of the secondary DNS server. The secondary DNS server is used if the primary DNS server is not available.
Domain name (suffix)	Defines the domain name of an existing DNS server.

3.4 How to Configure SNMP

SNMP (Simple Network Management Protocol) has become the standard protocol for the administration and monitoring of network elements. The protocol controls communication between the monitored devices and the monitoring station.

SNMP allows you to read and edit management information provided by the network elements (e.g. SND Server). The SND Server supports versions 1 and 3 of SNMP.

SNMPv1 The SNMP community is a basic form of access protection. A large number of SNMP managers are grouped together in the community. The community is then assigned (read/write) access rights. The general community string is 'public'.

The community string for SNMPv1 is transferred in plain text and does not provide sufficient protection.

- **SNMPv3** SNMPv3 is a continuation of the SNMP standard, which provides improved applications and a user-based security model. Distinguishing features of SNMPv3 include its simplicity and security concept.
 - Proceed as follows:
 - 1. Start the mySND Control Center.

- 2. Select NETWORK SNMP.
- 3. Configure the SNMP parameters; see: Table 5 \Rightarrow \exists 32.
- 4. Click Save & Restart to confirm.
- \checkmark The settings will be saved.

Table 5: SNMP Parameters

Parameters	Description
SNMPv1	Enables/disables SNMPv1.
Read-only	Enables/disables the write protection for the community.
Community	SNMP community name The SNMP community is a basic form of access protection in which several participants with the same access rights are grouped together.
SNMPv3	Enables/disables SNMPv3.
User name	Defines the name of the SNMP user.
Password	Defines the password of the SNMP user.
Hash	Defines the hash algorithm.
Access rights	Defines the access rights of the SNMP user.
Encryption	Defines the encryption method.

3.5 How to Configure POP3 and SMTP

You must configure the protocols POP3 and SMTP and email limits on the SND Server so that the notification service ($\Rightarrow \square 40$), the administration via email ($\Rightarrow \square 22$), the automatic file transfer ($\Rightarrow \square 53$) and the sending of files in the mySND File Browser ($\Rightarrow \square 64$) will work properly.

- **POP3** 'POP3' (Post Office Protocol Version 3) is a transfer protocol that a client can use to fetch emails from a mail server. POP3 is required in the SND Server to administer the SND Server via email.
- **SMTP** 'SMTP' (Simple Mail Transfer Protocol) is a protocol that controls the sending of emails in networks. SMTP is required in the SND Server to

	administer the SND Server via email, to operate the notification service and to transfer files automatically and send them from the mySND File Browser.
	The encryption and signing of emails via S/MIME is only possible for the administration via email and the notification service.
Email Limits	For the automatic file transfer (\Rightarrow \blacksquare 53) and the file sending in the mySND File Browser (\Rightarrow \blacksquare 64) you must define the maximum number of files and the total file size. This allows you to adhere to size restrictions for attachments that are set by the email provider.
What do you want to do?	 □ 'Configuring POP3' ⇒ ■33 □ 'Configuring SMTP' ⇒ ■34 □ 'Defining Email Limits' ⇒ ■36
	Configuring POP3
Requirements	The SND Server is set up as user with its own email address on a POP3 server.
	 Proceed as follows: Start the mySND Control Center. Select NETWORK - Email. Configure the POP3 parameters; see: Table 6 ⇔ 34. Click Save & Restart to confirm. The settings will be saved.

Table 6: POP3 Parameters

Parameters	Description
POP3	Enables/disables the POP3 functionality.
POP3 - Server name	Defines the POP3 server via the IP address or the host name. The host name can only be used if a DNS server was configured beforehand.
POP3 - Server port	Defines the port used by the SND Server for receiving emails. The port number 110 is preset. When using SSL/TLS, enter 995 as port number.
POP3 - Security	Defines the authentication method to be used (APOP/SSL/TLS). When using SSL/TLS, the cipher strength is defined via the encryption level $\Rightarrow \blacksquare 69$.
POP3 - Check mail every	Defines the time interval (in minutes) for retrieving emails from the POP3 server.
POP3 - Ignore mail exceeding	Defines the maximum email size (in Kbyte) to be accepted by the SND Server. (0 = unlimited)
POP3 - User name	Defines the user name used by the SND Server to log on to the POP3 server.
POP3 - Password	Defines the password used by the SND Server to log on to the POP3 server.

Configuring SMTP

Requirements

- ☑ The SND Server is set up as user with its own email address on an SMTP server.
- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select NETWORK Email.
- 3. Configure the SMTP parameters; see: Table 7 \Rightarrow 35.
- 4. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

Table 7: SMTP Parameters

Parameters	Description
SMTP - Server name	Defines the SMTP server via the IP address or the host name. The host name can only be used if a DNS server was configured beforehand.
SMTP - Server port	Defines the port number used by the SND Server to send emails to the SMTP server. The port number 25 is preset.
SMTP - TLS	Enables/disables TLS. The security protocol TLS (Transport Layer Security) is used to encrypt the transmission between the SND Server and the SMTP server. The cipher strength is defined via the encryption level $rightarrow effects$ 69.
SMTP - Sender name	Defines the email address used by the SND Server to send emails. Note: Very often the name of the sender and the user name are identical.
SMTP - Login	Enables/disables the SMTP authentication for the login.
SMTP - User name	Defines the user name used by the SND Server to log on to the SMTP server.
SMTP - Password	Defines the password used by the SND Server to log on to the SMTP server.
SMTP - Security (S/MIME)	Enables/disables the encryption and signing of emails via S/MIME. Note: Only emails from the administration and the notification service can be encrypted and signed.
SMTP - Signing emails	Defines the signing of emails. A signature created by the sender allows the recipient to verify the identity of the sender and to make sure that the email was not modified. An S/MIME certificate is required for the signing of emails $rightarrow$ 176.
SMTP - Full encryption	Defines the encryption of emails. Only the recipient can open and read the encrypted email. An S/MIME certificate is required for the encryption ⇔ 1676.
SMTP- Attach public key	Sends the public key together with the email. Many email clients require the public key to be attached in order to view the emails.

Defining Email Limits

- 💼 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select NETWORK Email.
- 3. Configure the email limits; see: Table 8 \Rightarrow \exists 36.
- 4. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

Table 8: Email Limits

Parameters	Description
SMTP - Total file size limit	Defines the total size limit (in kB) of the files that are sent via email during the file transfer via the mySND File Browser ($\Rightarrow \textcircled{B}64$) and the automatic file transfer ($\Rightarrow \textcircled{B}53$). If the defined value is exceeded, the remaining files will be sent in additional emails during the automatic file transfer.
SMTP - Maximum number of files	Defines the maximum number of files that are sent via email during the file transfer via the mySND File Browser $(\Rightarrow \textcircled{B}64)$ and the automatic file transfer $(\Rightarrow \textcircled{B}53)$. If the defined value is exceeded, the remaining files will be sent in additional emails during the automatic file transfer.

3.6 How to Configure Bonjour

Bonjour allows the automatic recognition of computers, devices, and network services in TCP/IP-based networks.

The SND Server uses the following Bonjour functions:

- Checking the IP address assigned via ZeroConf
- Assignment of host names to IP addresses
- Location of server services without knowledge of the device's host name or IP address.

When checking the IP address assigned via ZeroConf (see: 'ZeroConf' \Rightarrow 13) the SND Server sends a query to the network. If the IP address is no longer available in the network, the SND Server receives an answer. The SND Server then sends another query with a different IP address. If the IP address is available, it is saved in the SND Server.

The domain name service is used for additional Bonjour features. Since there is no central DNS server in Bonjour networks, each device and application has its own small DNS server.

This integrated DNS server (mDNS) collects and administers the information of all participants in the net. In addition to the features of a classical DNS server, the mDNS server also saves the IP address, the service name and the offered services of each participant.

- 💼 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select NETWORK Bonjour.
- 3. Configure the Bonjour parameters; see: Table 9 \Rightarrow 37.
- 4. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

Table 9: Bonjour Parameters

Parameters	Description
Bonjour	Enables/disables Bonjour.
Bonjour name	Defines the Bonjour name of the SND Server. The SND Server uses this name for its Bonjour services. If no Bonjour name is entered, the default name will be used (device name@ICxxxxx).

4 Device Settings



You can configure descriptions, the device time and the notification service on the SND Server. This chapter describes these device settings.

What information do you need?

- 'How to Configure the Device Time' ⇒
 ¹→
 ²
- 'How to Use the Notification Service' \Rightarrow B40

4.1 How to Determine a Description

You can assign freely definable descriptions to the SND Server. This gives you a better overview of the devices available in the network.

- 彦 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select DEVICE Description.
- 3. Enter freely definable names for Host name, Description and Contact person.
- 4. Click Save & Restart to confirm.
- ♦ The data is saved.

4.2 How to Configure the Device Time

You can control the device time of the SND Server via a time server (SNTP server) in the network. A timeserver is a computer networking device that reads the actual time from a reference clock and distributes this information to its clients. In the SND Server, the time server is defined via the IP address or the host name.

- **Benefits and Purpose** If the time server is enabled, the date and time of the last change will be displayed in the mySND File Browser according to the time set on the SND Server.
 - **UTC** The SND Server uses 'UTC' (Universal Time Coordinated) as a basis. UTC is a reference time and used as a time standard.
 - **Time zone** The time received by the time server does not necessarily correspond to your local time zone. Deviations from your location and the resulting time difference (including country-specific particularities such as Daylight Saving Time) can be handled by means of the 'Time zone' parameter.
- **Requirements** \square A time server is integrated into the network.
 - 醇 Proceed as follows:
 - 1. Start the mySND Control Center.
 - 2. Select DEVICE Date/Time.
 - 3. Tick Date/Time.
 - 4. Enter the IP address or the host name of the time server into the Time server box.
 (The host name can only be used if a DNS server was configured beforehand.)
 - (The nost name can only be used if a DNS server was configured beforenand.)
 - 5. Select the code for your local time zone from the Time zone list.
 - 6. Click Save & Restart to confirm.
 - \clubsuit The settings will be saved.

	4.3 How to Use the Notification Service
	You can get notifications in the form of emails or SNMP traps from the SND Server. By means of these notifications up to four recipients can be informed about various events irrespective of time and location.
	The following message types are possible:
	• The status email periodically informs the recipient about the status of the SND Server and the connected removable media.
	• The event notification informs you about a specific event on the SND Server via email or SNMP trap. The event can be:
	 The connection or disconnection of removable media to/from the SND Server.
	- The restart of the SND Server.
What do you want	\Box 'Configuring the sending of status emails' \Rightarrow 100
to do?	\square 'Configuring event notifications via email' \Rightarrow \square 41
	\square 'Configuring event notifications via SNMP traps' \Rightarrow \square 41
	Configuring the sending of status emails
Requirements	✓ SMTP parameters have been configured on the SND Server, see: ⇒ ⇒ ⇒ 32.
	☑ A DNS server has been configured on the SND Server; see: ⇒ ■30.
	For the notification service you can specify up to two email recipients.
	📴 Proceed as follows:
	1. Start the mySND Control Center.
	2. Select DEVICE - Notification.
	3. Enter the recipient into the Email address box.

4. Tick Status email.

- 5. Specify the sending interval in the Status notification time area.
- 6. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

Configuring event notifications via email

- Requirements SMTP parameters have been configured on the SND Server, see: ⇒

 32.
 - \blacksquare A DNS server has been configured on the SND Server; see: $\Rightarrow \square 30$.

For the notification service you can specify up to two email recipients and the message types.

- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select DEVICE Notification.
- 3. Enter the recipient into the Email address box.
- 4. Tick the options with the desired message types.
- 5. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

Configuring event notifications via SNMP traps

For the notification service you can specify up to two SNMP trap recipients and the message types.

- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select DEVICE Notification.
- 3. In the SNMP traps area, specify the recipients via the IP address and the community.
- 4. Tick the options with the desired message types in the Notifications area.
- 5. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

5 Media Management and Access **Settings** This chapter describes how to restrict the access to the SND Server, how to use removable media on the device and how to configure the file access. The access control on the SND server is handled via the user management. All user accounts can access the USB mass storage devices. The access to an SD card only takes place via user accounts that are assigned to this card. Exception: User accounts with administrator privilege can access all SD cards. Displayed file types are determined by the file filter that is assigned to the user account. Optionally you can configure an automatic file transfer. What information do vou need? 'How to Prepare Removable Media' ⇔🗎47 ٠ 'How to Configure the Media assignment' ⇒ ■48 'How to Configure File Filters' ⇒ ¹ 50 5.1 How to Manage User Accounts (Access Control) The access to the SND Server is controlled by means of user accounts. You will need a user name and a password to get access to the program. The user account 'Admin' and the password 'admin' have been

The user account 'Admin' and the password 'admin' have been configured by default. Change the password when you use the SND Server in a real situation. In addition to the predefined administrator account you can create 4 additional user accounts. If this number is reached, you must delete a user account before you can define a new one.

Login A user account allows for multiple logins, i.e. the account can be used by a single user or by a group of users. Up to 16 users can be logged on to the SND Server simultaneously. For further information; see: ⇔ 172

When logging in, the password is transmitted in plain text. We recommend setting up a secure connection (SSL/TLS); see: $\Rightarrow \blacksquare 70$.

Rights Each account will be equipped with rights for the work with files in the mySND File Browser and the administrative access (mySND Control Center).

Only system administrators should have access to the mySND Control Center because this is where security-related settings can be configured.

File Filters File types displayed in the mySND File Browser are determined by the file filter assigned. The file filter 'All files' is configured by default. To configure additional file filters; see: ⇒ 150.

Enabling/Disabling Accounts You can enable/disable a user account. This allows you to temporarily restrict the user access without having to delete or reconfigure the user account.

What do you want to do?

- □ 'Adding a User Account' ⇔ 🖹 44
- \Box 'Editing a User Account' \Rightarrow 45
- □ 'Enabling/Disabling a User Account' ⇔
 ■46

Adding a User Account

Proceed as follows:

- 1. Start the mySND Control Center.
- 2. Select FILE BROWSER User management.
- 3. Define the desired credentials in the Add user area; see: Table 10 ⇔ 🖹 44.
- 4. Tick the options with the desired rights; see: Table 10 \Rightarrow B 44.
- 5. Select the desired file filter; see: Table 10 \Rightarrow 144.
- 6. Click Save to confirm.
- \clubsuit The settings will be saved.

Table 10: User Account Parameters

Parameters	Description
Credentials	
User name	Defines the name for the user account in order to log on to the SND Server. (The name of the administrator account cannot be changed.)
Password	Defines the password for the user account in order to log on to the SND Server.
Retype	Re-entry of the password
Email address	Defines the email address suggestions for the automatic file transfer (\Rightarrow \blacksquare 40).
Rights	
Administration	Enables/disables the administrative access to the SND Server. All connected removable media can be displayed (no media assignment required). Only system administrators should have access to the mySND Control Center because this is where security-related settings can be configured. (The option cannot be disabled for the administrator account.)
Rename/Delete files	Enables/disables the feature for renaming and deleting files in the mySND File Browser.

Parameters	Description
Download files	Enables/disables the download feature in the mySND File Browser.
Email files	De-/aktiviert die E-Mail-Funktion im mySND File Browser.
Set/Clear archive bit	Enables/disables the archive bit feature in the mySND File Browser.
File access	
File filters	Defines a file filter for the user account. After logging on to the mySND File Browser, only files of the file types defined in the filter will be displayed. For further information; see: $rac{rac}{10}$ 150.

Editing a User Account

You can modify the settings of an existing user account.

Do not edit user accounts that are currently used by the SND Server. These accounts are marked with a green dot in the 'User status' table.

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Click FILE BROWSER User management.
- Click the
 F icon in the User status table for the user account to be modified. The Edit user dialog appears.
- 4. Make the desired modifications; see: Table 10 \Rightarrow \cong 44.
- 5. Click Save to confirm.
- \clubsuit The settings will be saved.

Deleting a User Account

Do not delete user accounts that are currently used by the SND Server. These accounts are marked with a green dot in the 'User status' table.

- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Click FILE BROWSER User management.
- 3. Click the **i** icon in the **User status** table for the user account to be deleted.
- 4. Confirm the security query by clicking Delete.
- The user account will be deleted.

Enabling/Disabling a User Account

Do not disable user accounts that are currently used by the SND Server. These accounts are marked with a green dot in the 'User status' table.

The administrator account cannot be disabled.

- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Click FILE BROWSER User management.
- Click the F icon in the User status table for the user account to be modified. The Edit user dialog appears.
- 4. Enables/disables the option in front of the user account name.
- 5. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

5.2 How to Prepare Removable Media

For a removable medium to be used on the SND Server, it must have the 'FAT32', 'FAT16' or 'FAT12' file system. You can format the removable medium on the SND Server accordingly. In the process a partition will be created spanning the entire removable medium.

Whether formatting is required, is displayed in the mySND Control Center under the 'Media preparation' menu item in the 'Media status' table.

To facilitate the identification of a removable medium, assign a freely definable name.

What do you want	
to do?	

- □ 'Renaming a Removable Medium' ⇔ 🖹 48

Formatting a Removable Medium

Requirements A removable medium is connected to the SND Server.

During the formatting process, all data on the removable medium will be permanently lost.

- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Click FILE BROWSER Media preparation.
- 3. Select the device type from the Removable medium list.
- 4. Enter a freely definable name into the Device name box.
- 5. Click Formatting.
- The removable medium will be formatted. This may take a few minutes.

Renaming a Removable Medium

Requirements

 \blacksquare A removable medium is connected to the SND Server.

- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Click FILE BROWSER Media preparation.
- 3. Select the device type from the Removable medium list.
- 4. Enter a freely definable name into the Device name box.
- 5. Click Rename.
- The removable medium will be renamed.

5.3 How to Configure the Media assignment

In order to restrict the access to SD cards on the SND Server, SD cards are assigned to user accounts. Only user accounts that are assigned to the SD card can access the removable medium via the mySND File Browser.

SD cards without media assignment can be used on the SND Server only with administrator privilege (\Rightarrow \blacksquare 42).

Media assignments (along with file filters \Rightarrow 150) reduce the risk of feeding unwanted data via the SND Server into the network.

We recommend disabling the USB port in order to further reduce the risk of feeding unwanted files into the network via the SND Server (\Rightarrow 173).

SD cards are identified via their device ID. Up to 16 media assignments can be configured.

What do you want	□ 'Establishing a Media Assignment' ⇔🖹49
to do?	□ 'Editing a Media Assignment' ⇔ 🖹 49
	□ 'Deleting a Media Assignment' ⇔\\$50
	Establishing a Media Assignment
Requirements	The SD card for which a media assignment is to be established, is connected to the SND Server.
	🚰 Proceed as follows:
	1. Start the mySND Control Center.
	2. Click FILE BROWSER - Media assignment.
	3. Enter a freely definable name into the Assignment name box.
	<i>4. In the</i> Users <i>area, enable the user accounts that are allowed to use the SD card.</i>
	5. Click Save to confirm.
	\checkmark The settings will be saved.
	Editing a Media Assignment
	You can modify the settings of an existing media assignment.
	🚰 Proceed as follows:
	1. Start the mySND Control Center.
	2. Click FILE BROWSER - Media assignment.
	 Click the F icon in the Media assignment status table for the media assignment to be edited. The Edit media assignment dialog appears.
	4. Enter a freely definable name into the Assignment name box.
	5. In the Users area, enable the user accounts that are allowed to use the SD card.

- 6. Click Save to confirm.
- The settings will be saved.

Deleting a Media Assignment

After the deletion of a media assignment, the access to the corresponding SD card via the mySND File Browser is only possible with administrator privilege ($\Rightarrow \triangleq 42$).

If a file transfer for the media assignment was configured, it will also be deleted.

- 醇 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Click FILE BROWSER Media assignment.
- 3. Click the **i** icon in the **Media assignment status** table for the media assignment to be deleted.
- 4. Confirm the security query by clicking Delete.
- 🔖 The media assignment will be deleted.

5.4 How to Configure File Filters

You can determine what file types will be displayed in the mySND File Browser for a certain user account. Define a file filter ($\Rightarrow \blacksquare 51$) and assign it to a user account ($\Rightarrow \blacksquare 42$).

This allows you to restrict the file access for the users.

The file filter 'All files' is defined by default and cannot be edited or deleted. You can freely define 4 additional file filters. If this number is reached, you must delete a file filter before you can define a new one.

On the SND Server, file types are defined by their file extension. Changing the file extension on a different device (PC, etc.) can lead to the fact that unwanted files will be fed into the network via the SND Server.

What do you want	☐ 'Adding a File Filter' ⇒ [●] 51
to do?	☐ 'Editing File Filters' ⇔
	☐ 'Deleting the File Filter' ⇔ ■52
	Adding a File Filter
	🚰 Proceed as follows:
	1. Start the mySND Control Center.
	2. Click FILE BROWSER - File filter.
	3. Enter a freely definable name into the Filter name box.
	 4. In the Accessible file types box, define the file types that will be displayed in the mySND File Browser. Enter the file extension: Schema: .<extension></extension> File types without extension will be defined by a dot. Multiple entries are to be separated by blanks.
	5. Click Save to confirm.
	$\stackrel{\mathrm{V}}{\hookrightarrow}$ The settings will be saved.
	Editing File Filters
	You can modify the settings of an existing file filter.
	📴 Proceed as follows:
	1. Start the mySND Control Center.
	2. Click FILE BROWSER – File filter.
	3. Click the $\mathbf{\mathcal{F}}$ icon in the File filter status table for the file filter to be modified.

- 4. Enter a freely definable name into the Filter name box.
- 5. In the Accessible file types box, define the file types that will be displayed in the mySND File Browser. Enter the file extension: - Schema: .< Extension>
 - File types without extension will be defined by a dot.
 - Multiple entries are to be separated by blanks.
- 6. Click Save to confirm.
- \clubsuit The settings will be saved.

Deleting the File Filter

After the deletion of a file filter, all user accounts to which this file filter was assigned to can longer view files in the mySND File Browser. Assign a new file filter to these user accounts ($\Rightarrow \square 45$).

- 💼 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Click FILE BROWSER File filter.
- 3. Click the **i** icon in the **File filter status** table for the file filter to be deleted.
- 4. Confirm the security query by clicking Delete.
- \clubsuit The file filter is deleted.

5.5 How to Configure the Automatic File Transfer

The automatic file transfer via email can be triggered when connecting removable media to the SND Server.

The files are transferred without encryption.

Transfer Method The method for the automatic file transfer is determined by the removable medium.

SD cards:

- card-specific transfer (One transfer is set up per SD card.)
- The automatic file transfer can only be set up for SD cards with media assignment.
- 1 recipient per SD card

USB mass storage devices:

- device-independent transfer (For all USB mass storage devices an overall transfer will be set up.)
- 2 recipients
- **Recipients** The recipients are freely definable. If you defined email addresses for the user accounts, these email addresses will be suggested as recipients.
 - **Content** Files from a specified folder will be transferred. The content from subfolders will not be transferred. Only defined file types will be transferred.
 - Limits Up to 10 files or 5000 kB can be sent in one email per default. If the defined value is exceeded, the remaining files will be sent in additional emails. You can modify these limits, see: ⇔ 🗎 36.
- Archive Bit Optionally, transferred files are marked by the archive bit **v**. Marked files will not be resent when the removable medium is

reconnected to the SND Server. Remove the archive bit to resend files, for example after a failed send attempt.

No archive bit can be set with read-only removable media.

Enable/Disable the
TransferYou can enable/disable automatic file transfers. This allows you disable
transfers without having to delete and reconfigure the file transfer.

What do you want to do?

- ☐ 'Editing File Transfers' ⇒ \u00e955
- □ 'Enabling/Disabling File Transfers' \Rightarrow \triangleq 55
- \Box 'Setting/clearing the archive bit' $\Rightarrow \textcircled{B}56$

Configuring File Transfers

Requirements Ø (only for SD cards) A media assignment was configured for the SD card; see: ⇔ ≅48.

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Click FILE BROWSER File transfer.
- 3. Select the device type from the Removable medium list.
- 4. Select the SD card from the list. (ony for SD cards)
- 5. Enter the email address of the addressee into the Recipient box.
- 6. In the **Source folder** box, enter the path to the source directory on the removable medium.
- 7. In the File types box, define the file types to be transferred by their file extension.
 - Schema: .<Extension>
 - File types without extension will be defined by a dot.
 - Multiple entries are to be separated by blanks.
- 8. Clear Set archive bit. (Optional)
- 9. Click Save to confirm.
- \clubsuit The settings will be saved.

Editing File Transfers

You can modify the settings of an existing file transfer.

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Click FILE BROWSER File transfer.
- 3. Click the *F* icon in the File transfer status table for the file transfer to be edited.
- 4. Select the SD card from the list. (ony for SD cards)
- 5. Enter the email address of the addressee into the Recipient box.
- 6. In the **Source folder** box, enter the path to the source directory on the removable medium.
- 7. In the Accessible file types box, define the file types to be transferred by their file extension.
 - Schema: .<Extension>
 - File types without extension will be defined by a dot.
 - Multiple entries are to be separated by blanks.
- 8. Tick/clear Set archive bit. (Optional)
- 9. Click Save to confirm.
- \clubsuit The settings will be saved.

Enabling/Disabling File Transfers

- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Click FILE BROWSER File transfer.
- 3. Click the \mathcal{F} icon in the File transfer status table for the file transfer to be disabled.
- 4. Clear Enable.
- 5. Click Save to confirm.
- \clubsuit The settings will be saved.

Deleting File Transfers Proceed as follows: 1. Start the mySND Control Center. 2. Click FILE BROWSER - File transfer. 3. Click the 💼 icon in the File transfer status table for the file transfer to be deleted. 4. Confirm the security query by clicking Delete. \checkmark The file transfer is deleted. Setting/clearing the archive bit **Requirements** \square A removable medium is connected to the SND Server. \square Files are available on the removable medium. \blacksquare The user account used has the right to set and clear archive bits; see: ⇒∎42. Proceed as follows: 1. Start the mySND File Browser. 2. Click SD or USB. The removable medium is selected. 3. Select a folder. The files are displayed. 4. Select the files to be modified. 5. Select Set archive bit or Clear archive bit from the shortcut menu.

 \clubsuit The archive bit is set/cleared.

6 Working with the mySND File Browser



The access to the removable media that are connected to the SND Server and the files stored on them is done via the mySND File Browser. This chapter describes how to access and work with files.

What information do you need?

- 'How to Display Files in the mySND File Browser' ⇔

 B60
- 'How to Select Files' ⇔ 🖹 61
- 'How to Sort Files' $\Rightarrow \blacksquare 62$
- 'How to Search Files' ⇔

 B63
- 'How to Store Files on a Client' ⇒

 B64
- 'How to Delete Files' ⇔

 B66
- 'How to Rename Files' ⇔

 B65

6.1 How to Use the mySND File Browser

The mySND File Browser is the user interface for the file access. It shows the files saved on the removable medium that is connected to the SND Server.

The mySND File Browser is stored in the SND Server and can be displayed by means of a browser software (Internet Explorer, Firefox, Safari).

The access to the mySND File Browser is controlled by means of user accounts (rightarrow 42). Users authenticate themselves via a user name and a password.

Start and Login The login to the SND server is session-based. Up to 16 users can be logged on to the SND server at the same time. For further information; see: \Rightarrow 27.

- **Requirements** If The SND Server is connected to the network and the mains voltage.
 - \square The SND Server has a valid IP address.

The user account 'Admin' and the password 'admin' have been configured by default. Change the password when you use the SND server in a real situation; see: $\Rightarrow \textcircled{B}42$.

- 📴 Proceed as follows:
- 1. Open your browser.
- Enter the IP address of the SND Server as the URL. The login page appears. If the login page is not displayed, check the proxy settings of the browser.
- 3. Enter the user name and password of a user account.
- 4. Click Login.
- The mySND File Browser will be displayed in the browser.

You can also start the mySND File Browser via the software tool 'InterCon-NetTool'.

Proceed as follows:

- 1. Highlight the SND Server in the device list.
- 2. Select Actions Launch Browser from the menu bar. The login page appears.
- 3. Enter the user name and password of a user account.
- 4. Click Login.
- The mySND File Browser will be displayed.

Structure and Mode of Operation of the mySND File Browser After the logging the mySND File Browser will be displayed with the following dialog items:

Selection of the remova	able medium Path	Search feature
Firefox • Siki 10.168.1.151 - mySND File Browser •<		C C C Coogle P C Control Cern C C
	mySND File Browser	?
Folders	SD USB Files Project A	
SD card_1	Name	Modified Size
Project A Project B	Concept.docx	2013-04-15 06:57 664 Kb 2013-04-15 06:58 1681 Kb
Project C	Figure 1.jp	2013-04-15 06:58 764 Kb
inoject o	Figure 2.jp Download Figure 3.jp	2013-04-15 06:58 1005 Kb
	Figure 4 in	2013-04-18 09:34 1681 Kb
	E Figure 5.jp	2013-04-18 09:34 764 Kb 📻
	Figure 6.jp Set archive bit	2013-04-18 09:34 1005 Kb
	Karketing. × Delete	2013-04-18 09:34 520 Kb
	Presentation.ppt	2013-04-18 09:34 1360 Kb
	E Production.pdf	2013-04-15 07:01 1519 Kb
] Timeline.xlsx	2013-04-15 07:03 7684 Byte
Sitemap Product & Company	1 1 10, updated on 21-01-19 09:30, using	Copyright © 2013 EH Computertechnik GmbH
Navigation pane	Shortcut menu	File display pane

Fig. 6: mySND File Browser

The buttons for the selection of the removable medium (top left) determine from what removable medium the content will be displayed in the file display pane (right). The navigation pane (left) and the path (top) allow for the orientation and navigation on the removable medium. Working with files (e.g. download) is done via the corresponding button (top right) or the shortcut menu (right-click).

You can choose your language by clicking the relevant flag.

Important information (IP address, host name, user account) is displayed at the top. The IP address allows you to directly go to the login page.

The manufacturer's contact details and additional information regarding the product are displayed under **Product & Company**.

Users with administrator privileges can click **Control Center** to go to the pane with the same name. The **Sitemap** provides administrators with an overview of and direct access to all pages of the mySND Control Center.

- **Logout** Up to 16 users can be logged on to the SND server at the same time. If this number is reached, further logins will fail. Log off in order to allow other users to access the SND server.
 - 醇 Proceed as follows:
 - 1. Click Logout.
 - ✤ The login page appears. You have successfully logged out.

Detailed information about the work with the mySND File Browser can be found in the following chapters or in the SND Server Online Help. To start the Online Help, click the 2 icon.

6.2 How to Display Files in the mySND File Browser

In the mySND File Browser, files will be displayed that are stored on a removable medium that is connected to the SND Server.

Displayed file types are determined by the file filter that is defined for the user account used; see: \Rightarrow 1000 50.

Requirements A removable medium is connected to the SND Server.

 \blacksquare Files are available on the removable medium.

- Proceed as follows:
- 1. Start the mySND File Browser.
- 2. Click SD or USB. The removable medium is selected.

	 Select a folder. (To show or hide subfolders, click the triangular icon in front of the folder.) The file content will be displayed.
	6.3 How to Select Files
	To work with one or more files, you have to select the files.
What do you want	□ 'Selecting a Single File' ⇒ ■61
to do?	\Box 'Selecting Consecutive Files' \Rightarrow \textcircled{B} 61
	□ 'Selecting Non-Consecutive Files' \Rightarrow \textcircled{B} 62
	Selecting a Single File
Requirements	\blacksquare A removable medium is connected to the SND server.
	\blacksquare Files are available on the removable medium.
	 Proceed as follows: 1. Start the mySND File Browser. 2. Click SD or USB. The removable medium is selected. 3. Select a folder. The files are displayed. 4. Select the desired file. She file is marked.
	Selecting Consecutive Files
Requirements	\blacksquare A removable medium is connected to the SND server.
	\blacksquare Files are available on the removable medium.
	Proceed as follows:
	1. Start the mySND File Browser.

	 Click SD or USB. The removable medium is selected. Select a folder. The files are displayed. Select the first file from your selection. Keep the SHIFT key pressed and select the last file from your selection.
	Selecting Non-Consecutive Files
Requirements	\square A removable medium is connected to the SND server.
-	\blacksquare Files are available on the removable medium.
	🚰 Proceed as follows:
	1. Start the mySND File Browser.
	2. Click SD or USB. The removable medium is selected.
	3. Select a folder. The files are displayed.
	4. Windows/Linux: Keep the Alt Gr key pressed. Mac: Keep the command key pressed.
	5. Select the individual files.
	$\stackrel{\scriptstyle{\leftarrow}}{\hookrightarrow}$ The files are marked.
	6.4 How to Sort Files
	You can sort the currently displayed files in the mySND File Browser by various criteria:
	• name
	• size

- change date
- file extension and
- archive bit

Requirements	\blacksquare A removable medium is connected to the SND Server.
	\blacksquare Files are available on the removable medium.
	🚰 Proceed as follows:
	1. Start the mySND File Browser.
	2. Click SD or USB. The removable medium is selected.
	3. Select a folder. The files are displayed.
	4. Select the column heading to be sorted by.
	😓 The files displayed are sorted.
	(The icon of an arrow in front of the column heading shows the sort order. To reverse the sort order, select the column heading again.)
	6.5 How to Search Files
	You can sort the currently displayed files in the mySND File Browser by freely definable criteria such as the file name.
Requirements	\blacksquare A removable medium is connected to the SND Server.
	\blacksquare Files are available on the removable medium.
	📴 Proceed as follows:
	1. Start the mySND File Browser.
	2. Click SD or USB.
	The removable medium is selected.
	3. Select a folder. The files are displayed.
	4. Click the icon \mathbb{Q} . The search field appears.
	5. Enter a search criterion into the search box.
	\checkmark The search result is displayed.
	To end the search, click the \mathbf{X} icon.

6.6 How to Store Files on a Client

One or more files can be stored locally on your client. Several files are grouped in a zip file.

For performance reasons we recommend that you do not store more than 160 files in one download process. **Requirements** \square A removable medium is connected to the SND Server. \square Files are available on the removable medium. \square The user account used has download privileges; see: $\Rightarrow \square 42$. Proceed as follows: 1. Start the mySND File Browser. 2. Click SD or USB. The removable medium is selected. 3. Select a folder. The files are displayed. 4. Select the desired files. The Download button appears. 5. Click Download. 6. Save the file selection to your local system by means of your browser. The file selection is copied to your client. 6.7 How to Email Files via the mySND File Browser

You can send the files displayed in the mySND File Browser via email.

The files are transferred without encryption.

Limits Up to 10 files or 5000 kB can be sent in one email per default. You can modify these limits, see: \Rightarrow \exists 36.

Requirements	\checkmark	A removable medium is connected to the SND Server.
	\checkmark	Files are available on the removable medium.
	\checkmark	The user account used has email privileges; see: ⇒\`````\$42.
	V	SMTP parameters have been configured on the SND Server; see: $\Rightarrow \blacksquare 32$.
	V	A DNS server has been configured on the SND Server; see: \Rightarrow \Rightarrow 30.
		Proceed as follows:
	1.	Start the mySND File Browser.
	2.	Click SD or USB. The removable medium is selected.
	3.	Select a folder.
	1	The files are displayed. Select the desired files.
		Select Email to from the shortcut menu.
	5.	The Email files dialog appears.
	6.	Enter the email address of the addressee into the Recipients box.
	7.	Define a subject. (Optional)
	8.	Click Send.
	$\not\in$	The file selection is sent.
	6.8	B How to Rename Files
		es stored on a removable medium can be renamed via the mySND Browser.
	File	s can only be renamed one after the other.
Requirements	\checkmark	A removable medium is connected to the SND Server.
	\checkmark	Files are available on the removable medium.
	\checkmark	The user account used has renaming privileges; see: ⇔\242.

Do not change the file extension. Otherwise the file will become unusable or cannot be displayed in the mySND File Browser.

- Proceed as follows:
- 1. Start the mySND File Browser.
- 2. Click SD or USB. The removable medium is selected.
- 3. Select a folder. The files are displayed.
- 4. Select the file to be renamed.
- 5. Select Rename from the shortcut menu.
- 6. Enter a new file name.
- 7. Press Enter.
- \checkmark The file is renamed.

6.9 How to Delete Files

Files stored on a removable medium can be deleted via the mySND File Browser.

Deleted files will be permanently lost.

Requirements A removable medium is connected to the SND Server.

 \blacksquare Files are available on the removable medium.

- \blacksquare The user account used has deleting privileges; see: \Rightarrow \blacksquare 42.
- Proceed as follows:
- 1. Start the mySND File Browser.
- 2. Click SD or USB. The removable medium is selected.
- 3. Select a folder. The files are displayed.

- 4. Select the files to be deleted.
- *5. Select* **Delete** *from the shortcut menu.*
- 6. Confirm the security query by clicking Delete.
- \clubsuit The file selection is deleted.

7 Security A number of security mechanisms are available to ensure optimum security for the SND Server. This chapter describes how to make use of these security mechanisms. The following security mechanisms can be configured and activated according to your demands: What information do • 'How to Define the Encryption Level for SSL/TLS Connections' you need? • 'How to Control the Access to the mySND File Browser and the • 'How to Manage Sessions' ⇔ ☐72 • 'How to Enable/Disable the USB Port' ⇒ ■73 • 'How to Control the Access to the SND Server (TCP Port Access • 'How to Use Certificates Correctly' ⇒ [□]76 'How to Use Authentication Methods' ⇒ ■84

7.1 How to Define the Encryption Level for SSL/TLS Connections

The following connections on the SND Server can be encrypted via SSL/TLS:

- Email: POP3 (⇔≣32)
- Email: SMTP (⇔ 🖹 32)

In the case of POP3 and SMTP only the administration via email and the notification service will be encrypted. The automatic file transfer and the file transfer via the mySND File Browser are carried out without encryption.

Encryption Level The encryption strength and thus the safety of the connection is defined via the encryption level.

Cipher Suite Each encryption level is a collection of so-called cipher suites. A cipher suite is a standardized sequence of four cryptographic algorithms that are used to establish a secure connection. Depending on their cipher strength (in bit), cipher suites are grouped to form an encryption level. Which cipher suites are supported by the SND Server, i.e. are part of an encryption level, depends on the protocol used (SSLv2, SSLv3, TLSv1).

Establishing Connections When establishing a secure connection, a list of supported cipher suites is sent to the communicating party. A cipher suite is agreed upon that will be used later on. The strongest cipher suite that is supported by both parties will be used by default. If there is no cipher suite that is supported by both parties, no SSL/TLS connection will be established.

> The communicating parties of the SND Server (e.g. browser) must support the cipher suites of the selected encryption level in order

to successfully establish a connection. When problems occur, select a different level or reset the SND Server parameters; see: $\Rightarrow \textcircled{B}93$.

The following encryption levels can be selected:

- **Compatible:** Cipher suites with an encryption of 40 to 256 bit will be used.
- Low: Only cipher suites with a low encryption of 56 bit will be used. (Fast connection)
- Medium: Only cipher suites with an encryption of 128 bit will be used.
- **High:** Only cipher suites with a strong encryption of 128 to 256 bit will be used. (Slow connection)
- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select SECURITY SSL connections.
- 3. Select the desired encryption level from the Encryption area.
- 4. Click Save & Restart to confirm.
- 5. The setting will be saved.

Detailed information about the individual SSL connection status (e.g. cipher suites) can be found on the Details page at SSL connection status - Details.

7.2 How to Control the Access to the mySND File Browser and the mySND Control Center

You can restrict the web access to the SND Server.

What do you want to do?

- \square 'Specifying the Permitted Web Connection Type' \Rightarrow 171
- \square 'Protecting the web access via password' $\Rightarrow \square 71$

The mySND Control Center can also be protected by the SNMP security concept. The concept includes administration of user groups and access rights. For further information; see: 'How to Configure SNMP' \Rightarrow 131.

Specifying the Permitted Web Connection Type

Types of Connection (HTTP/HTTPS) The web access to the mySND Control Center and the mySND File Browser can be secured by selecting the permitted types of connection (HTTP/HTTPS).

If HTTPS is exclusively chosen as the connection type, the web access to the mySND File Browser and the mySND Control Center is protected by SSL/TLS. The cipher strength is defined via the encryption level \Rightarrow 169.

SSL/TLS requires a certificate to check the identity of the SND Server. During a so-called 'handshake', the client asks for a certificate via a browser. This certificate must be accepted by the browser. Please refer to the documentation of your browser software. URLs that require an SSL/TLS connection start with 'https'.

- 醇 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select SECURITY Device access.
- 3. Tick HTTP/HTTPS or HTTPS only in the Web area.
- 4. Click Save & Restart to confirm.
- \clubsuit The setting will be saved.

Protecting the web access via password

The access to the mySND Control Center and the mySND File Browser is controlled by means of user accounts; see: $\Rightarrow \blacksquare 42$.

7.3 How to Manage Sessions

A user account allows for multiple logins on the SND Server, i.e. the account can be used by a single user or by a group of users.

The login is session-based. Up to 16 sessions can be saved at the same time. This means that up to 16 users can be logged on to the SND Server at the same time.

If this number is reached, further logins will fail. Sessions are terminated and are available for new logins if a user logs out ($\Rightarrow B60$ and $\Rightarrow B19$) or the session timeout expires. Administrators also have the possibility to terminate current sessions.

What do you want to do?

- \Box 'Configuring a Session Timeout' \Rightarrow 272
- □ 'Terminating Sessions' ⇔ 173

Configuring a Session Timeout

Session timeout means that the connection to the mySND File Browser and the mySND Control Center will be terminated for security reasons after a period of inactivity. The user will be logged out and has to log on to the SND Server again. Set the time period for the session timeout.

- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select SECURITY Device access.
- 3. Tick Session Timeout.
- 4. In the Session duration box, enter the time in seconds after which the timeout is to be effective.
- \clubsuit The setting will be saved.

Terminating Sessions

Users whose sessions are terminated lose their access to the SND Server and are required to login again. Current actions (file download, etc.) will be stopped.

Requirements The SND Server is connected to the network and the mains voltage.

- □ The SND Server has a valid IP address.
- \Box The used user account has administrator privileges; see: $\Rightarrow \square 42$.
- 📴 Proceed as follows:
- 1. Open your browser.
- 2. Enter the IP address of the SND Server as the URL. The login page appears.
- 3. Enter the user name and password of a user account.
- 4. Click Sessions. The page mySND sessions appears.
- 5. In the **Current sessions** table, click the **i** icon for the session to be terminated.
- 6. Confirm the security query by clicking End.
- \clubsuit The session is terminated.

7.4 How to Enable/Disable the USB Port

The USB port on the SND Server is disabled by default.

The media assignment allows you to control the access to the SD cards on the SND Server ($\Rightarrow \blacksquare 48$). Every user that is logged in can access a USB mass storage device.

If the USB port is not needed, we recommend disabling this interface for security reasons. This reduces the risk of feeding unwanted files into the network via the SND server.

	 Proceed as follows: Start the mySND Control Center. Select SECURITY - Device access. Tick/clear USB port in the Interfaces area. The setting will be saved.
	7.5 How to Control the Access to the SND Server (TCP Port Access Control)
TCP Port Access Control	You can control the access to the SND Server. To do so, various TCP port types on the SND Server can be blocked. Network elements with access rights can be defined as exceptions and excluded from blocking. The SND Server only accepts data packets from network elements defined as exceptions.
Security Levels	The port types to be blocked must be defined in the 'Security level' area. The following categorization can be selected:
	 Lock TCP access (locks TCP ports: HTTP/HTTPS)
	• Lock all (locks IP ports)
Exceptions	In order to exclude network elements (e.g. clients, DNS server, SNTP server) from port locking, they must be defined as exceptions. To do so, the IP addresses or MAC addresses (hardware addresses) of the network elements with access rights must be entered in the 'Exceptions' area. Please note:
	 MAC addresses are not delivered through routers!
	• The use of wildcards (*) allows you to define subnetworks.
Test Mode	The 'test mode' allows you to check the configured access protection. If the test mode is activated, access protection remains active until the SND Server is rebooted. After restarting, the protection is no longer effective.

The 'test mode' option is activated by default. After a successful test, you must deactivate the test mode so that access protection remains permanently active.

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select SECURITY TCP port access.
- 3. Tick Port access control.
- 4. Select the desired protection in the Security level area.
- 5. In the Exceptions area, define the network elements which are excluded from port blocking. Enter the IP or MAC addresses and tick the options.
- 6. Make sure that the test mode is enabled.
- 7. Click Save & Restart to confirm. The settings are saved. The port access control is activated until the device is restarted.
- 8. Check the port access and configurability of the SND Server.

If the SND Server can no longer be reached using the mySND Control Center, restart the device; see: rightarrow 97.

- 9. Clear Test mode.
- 10. Click Save & Restart to confirm.
- The settings will be saved. The port access control is active. Access to the ports is restricted.

7.6 How to Use Certificates Correctly

The SND Server has its own certificate management. This section explains how certificates are used and when the use of certificates is recommended.

What are Certificates? Certificates can be used in TCP/IP-based networks to encrypt data and to authenticate communication partners. Certificates are electronic messages containing a key (public key) and a signature.

Benefits and Purpose The use of certificates allows for various security mechanisms. Use certificates in the SND Server

- to check the identity of the SND Server in the network; see: 'Configuring EAP-TLS' ⇔
 85.
- to authenticate the SND Server/client if the access to the mySND File Browser and the mySND Control Center is protected via HTTPS (SSL/TLS); see: ⇒ ■71.

If you use certificates, you should only grant administrator privileges to administrators to prevent unauthorized persons from deleting certificates on the SND Server; see: \Rightarrow 242.

Which Certificates are available?

Both self-signed certificates and CA certificates can be used with the SND Server. The following certificates can be distinguished:

- Upon delivery, a certificate (the so-called **default certificate**) is stored in the SND Server. It is recommended that you replace the default certificate by a self-signed certificate or CA certificate as soon as possible.
- Self-signed certificates have a digital signature that has been created by the SND Server.
- **CA certificates** are certificates that have been signed by a certification authority (CA).
- The authenticity of the CA certificate can be verified by means of a so-called **root certificate** issued by the certification

authority. The root certificate is stored on an authentication server in the network.

• S/MIME certificates (*.pem file) are used to sign and encrypt the emails that are sent by the SND Server in the course of the administration via email and the notification service. The corresponding private key must be installed as an own certificate in the PKCS#12 format (as *.p12 file) in the intended email program (Thunderbird, Outlook, etc.). Only then can the emails be verified and displayed (in the case of encryption).

The following certificates can be installed at the same time in the SND Server:


- 1 Self-signed certificate
- 1 CA certificate or PKCS#12 certificate
- 1 Root certificate
- 1 S/MIME certificate

You can also generate a certificate request for a CA certificate. All certificates can be deleted separately. Existing certificates will be overridden when installing or generating new certificates.

A PKCS#12 certificate can only be installed if there are currently no certificate requests or CA certificates installed.

Certificates status			
Туре	Status	Action	
Self-signed certificate	Installed	Q ±	
Certificate request	Not generated		
CA certificate	Not installed		
Root certificate	Not installed		
S/MIME certificate	Not installed		

Fig. 7: mySND Control Center - Certificates



- \square 'Saving the S/MIME Certificate on the SND Server' \Rightarrow 82
- □ 'Deleting Certificates' ⇔ 🖹 83

Displaying Certificates

Certificates installed on the SND Server and certificate requests can be displayed and viewed.

- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select SECURITY Certificates.
- 3. Select the certificate via the icon \mathbf{Q} .
- \clubsuit The certificate is displayed.

Creating a Self-Signed Certificate

If a self-signed certificate has already been created on the SND Server, you must first delete the certificate; see: \Rightarrow \mathbb{B} 83.

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select SECURITY Certificates.
- 3. Click Self-signed certificate.
- 4. Enter the relevant parameters; see: Table 11 \Rightarrow 29.
- 5. Click Install.

So The certificate will be created and installed. This may take a few minutes.

Table 11: Parameters for the Creation of Certificates

Parameters	Description
Common name	Is used to clearly identify the certificate. It is advisable to use the IP address or the host name of the SND Server to allow a clear assignment of the certificate to the SND Server. You can enter a maximum of 64 characters.
Email address	Specifies an email address. You can enter a maximum of 40 characters. (Optional Entry)
Organization name	Specifies the company that uses the SND Server. You can enter a maximum of 64 characters.
Organizational unit	Specifies the department or subsection of a company. You can enter a maximum of 64 characters. (Optional Entry)
Location	Specifies the locality where the company is based. You can enter a maximum of 64 characters.
State name	Specifies the state in which the company is based. You can enter a maximum of 64 characters. (Optional Entry)
Domain component(s)	Allows you to enter additional attributes. (Optional Entry)
Country	Specifies the country in which the company is based. Enter the two-digit country code according to ISO 3166. Examples: DE = Germany, GB = Great Britain, US = USA
Issued on	Specifies the date from which on the certificate is valid.
Expires on	Specifies the date from which on the certificate becomes invalid.
RSA key length	Defines the length of the RSA key used: - 512 bit (fast encryption and decryption) - 768 bit - 1024 bit (standard encryption and decryption) - 2048 bit (slow encryption and decryption)

Creating a Certificate Request for CA Certificates

As a preparation for the use of a CA certificate, a certificate request that has to be sent to the certification authority can be created in the SND Server. The certification authority will then create a CA certificate on the basis of the certificate request. The certificate must be in base64 format.

If a certificate request has already been created on the SND Server, you must first delete the certificate request; see: \Rightarrow 83.

醇 Proceed as follows:

- 🚮

- 1. Start the mySND Control Center.
- 2. Select SECURITY Certificates.
- 3. Click Certificate request.
- 4. Enter the required parameters, see: Table 11 \Rightarrow 29.
- 5. Click **Create a request**. The creation of the certificate request is in progress. This may take a few minutes.
- 6. Click Save and save the request in a text file.
- 7. Click OK.
- 8. Send the text file as certificate request to a certification authority.

When the CA certificate has been received, it must be saved in the SND Server; see: $\Rightarrow B 80$.

Saving the CA Certificate in the SND Server

If a CA certificate has already been installed on the SND Server, it will be overwritten.

Requirements

- ☑ A certificate request has been created at an earlier date; see: \Rightarrow в 80.
- \blacksquare The certificate must be in base64 format.

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select SECURITY Certificates.
- 3. Click CA certificate.
- 4. Click Browse.
- 5. Specify the CA certificate.
- 6. Click Install.
- The CA certificate will be saved in the SND Server.

Saving the Root Certificate on the SND Server

The SND Server offers a number of authentication methods to verify its identity in a network. If you use the authentication method 'EAP-TLS' (\Rightarrow 185), you must install the root certificate of the authentication server (RADIUS) on the SND Server.

If a root certificate has already been installed on the SND Server, it will be overwritten.

- **Requirements** \square The certificate must be in base64 format.
 - 📴 Proceed as follows:
 - 1. Start the mySND Control Center.
 - 2. Select SECURITY Certificates.
 - 3. Click Root certificate.
 - 4. Click Browse.
 - 5. Specify the root certificate.
 - 6. Click Install.
 - The root certificate is saved in the SND Server.

Saving PKCS#12 Certificates on the SND Server

Certificates with the PKCS#12 format are used to save private keys and their respective certificates and to protect them by means of a password.

If a PKCS#12 certificate has already been installed on the SND Server, it will be overwritten.

- **Requirements** I The certificate must be in base64 format.
 - ✓ No certificate request may exist. To delete the certificate request, see: ⇒ ≅83.
 - ☑ No CA certificate may be installed. To delete a CA certificate, see: ⇒ ■83.
 - 📴 Proceed as follows:
 - 1. Start the mySND Control Center.
 - 2. Select SECURITY Certificates.
 - 3. Click PKCS#12 certificate.
 - 4. Click Browse.
 - 5. Enter the PKCS#12 certificate.
 - 6. Enter the password.
 - 7. Click Install.
 - ✤ The PKCS12 certificate is saved on the SND Server.

Saving the S/MIME Certificate on the SND Server

S/MIME certificates (*.pem file) are used to sign and encrypt the emails that are sent by the SND Server in the course of the administration via email (\Rightarrow B22) and the notification service (\Rightarrow B40).

If an S/MIME certificate has already been installed on the SND Server, it will be overwritten.

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select SECURITY Certificates.
- 3. Click S/MIME certificate.
- 4. Click Browse.
- 5. Specify the S/MIME certificate.
- 6. Click Install.
- The S/MIME certificate will be saved on the SND Server.

Deleting Certificates

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select SECURITY Certificates.
- 3. Select the certificate to be deleted via the icon **Q**. The certificate is displayed.
- 4. Click Delete.
- \clubsuit The certificate is deleted.

7.7 How to Use Authentication Methods

By means of an authentication, a network can be protected against unauthorized access. The SND Server can participate in various authentication procedures. This section describes which procedures are supported and how these procedures are configured on the SND Server.

- What is IEEE 802.1x? The IEEE 802.1x standard provides a basic structure for various authentication and key management protocols. IEEE 802.1x allows you to control the access to networks. Before users gain access to a network via a network device, they must authenticate themselves in the network. After the authentication was successful, the access to the network will be freed.
 - What is EAP? The standard IEEE 802.1x is based upon the EAP (Extensible Authentication Protocol). EAP is a universal protocol for many authentication procedures. EAP allows for a standardized authentication procedure between the network device and an authentication server (RADIUS). First you must define the authentication procedure (TLS, PEAP, TTLS, etc.) to be used and configure it on all network devices involved.
 - **What is RADIUS?** RADIUS (Remote Authentication Dial-In User Service) is an authentication and account management system that validates user login information and grants access to the desired resources.

The SND Server supports various EAP authentication methods in order to authenticate itself in a protected network.

- What do you want to do? □ 'Configuring EAP-MD5' ⇔ ■85
 - □ 'Configuring EAP-TLS' \Rightarrow 85
 - □ 'Configuring EAP-TTLS' \Rightarrow B86
 - □ 'Configuring PEAP' \Rightarrow $\mathbb{B}88$
 - □ 'Configuring EAP-FAST' \Rightarrow \mathbb{B} 89

Configuring EAP-MD5

Benefits and Purpose EAP-MD5 validates the identity of devices or users before they gain access to network resources. You can configure the SND Server for the EAP-MD5 network authentication. This makes sure that the SND Server gets access to protected networks.

Mode of Operation EAP-MD5 describes a user-based authentication method via a RADIUS server. The SND Server must be defined as user (with user name and password) on a RADIUS server. The authentication method EAP-MD5 must then be enabled on the SND Server and the user name and password need to be entered.

Requirements ✓ The SND Server is defined as user (with user name and password) on a RADIUS server.

- 彦 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select SECURITY Authentication.
- 3. Select MD5 from the Authentication method list.
- 4. Enter the user name and the password that are used for the configuration of the SND Server on the RADIUS server.
- 5. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

Configuring EAP-TLS

Benefits and Purpose EAP-TLS (Transport Layer Security) validates the identity of devices or users before they gain access to network resources. You can configure the SND Server for the EAP-TLS network authentication. This makes sure that the SND Server gets access to protected networks.

Mode of Operation EAP-TLS describes a certificate-based authentication method via a RADIUS server. For this purpose, certificates are exchanged between the SND Server and the RADIUS server. An encrypted TLS connection between the SND Server and the RADIUS server is established in this process. Both RADIUS server and SND Server need a valid, digital

certificate signed by a CA. The RADIUS server and the print server must validate the certificate. After the mutual authentication was successful, the access to the network will be freed.

Since each device needs a certificate, a PKI (Public Key Infrastructure) must be available. User passwords are not necessary.

If you want to use the EAP-TLS authentication, you must observe the instructions below in the indicated order. If this procedure is not adhered to, the SND Server in the network may not be addressable. In this case you have to reset the SND Server parameters; see: \Rightarrow \Rightarrow 33.

- **Procedure** Create a certificate request on the SND Server; see: $\Rightarrow \blacksquare 80$.
 - Create a CA certificate using the certificate request and the authentication server.
 - Save the CA certificate on the SND Server; see: $\Rightarrow \blacksquare 80$.

 - Enable the authentication method 'EAP-TLS' on the SND Server.
 - 🚰 Proceed as follows:
 - 1. Start the mySND Control Center.
 - 2. Select SECURITY Authentication.
 - 3. Select TLS from the Authentication method list.
 - 4. Click Save & Restart to confirm.
 - \clubsuit The settings will be saved.

Configuring EAP-TTLS

Benefits and Purpose

d EAP-TTLS (Tunneled Transport Layer Security) validates the identity of devices or users before they gain access to network resources. You can configure the SND Server for the EAP-TTLS network authentication. This makes sure that the SND Server gets access to protected networks.

Mode of Operation	EAP-TTLS consists of two phases:		
	 In phase 1, a TLS-encrypted channel between the SND Server and the RADIUS server will be established. Only the RADIUS server authenticates itself on the SND Server using a certificate that was signed by a CA. This process is also referred to as 'outer authentication'. 		
	 In phase 2, an additional authentication method is used for the communication within the TLS channel. EAP-defined methods and older methods (CHAP, PAP, MS-CHAP und MS-CHAPv2) are supported. This process is also referred to as 'inner authentication'. 		
	The advantage of this procedure is that only the RADIUS server needs a certificate. Therefore no PKI is needed. Moreover, TTLS supports most authentication protocols.		
Requirements	The TPG is defined as user (with user name and password) on a RADIUS server.		
	📴 Proceed as follows:		
	1. Start the mySND Control Center.		
	 Start the mySND Control Center. Select SECURITY – Authentication. 		
	,		
	2. Select SECURITY – Authentication.		
	 Select SECURITY – Authentication. Select TTLS from the Authentication method list. Enter the user name and the password that are used for the 		
	 Select SECURITY – Authentication. Select TTLS from the Authentication method list. Enter the user name and the password that are used for the configuration of the SND Server on the RADIUS server. Select the settings intended to secure the communication in the 		
	 Select SECURITY – Authentication. Select TTLS from the Authentication method list. Enter the user name and the password that are used for the configuration of the SND Server on the RADIUS server. Select the settings intended to secure the communication in the TLS channel. To make the connection more secure, you can also install the 		
	 Select SECURITY - Authentication. Select TTLS from the Authentication method list. Enter the user name and the password that are used for the configuration of the SND Server on the RADIUS server. Select the settings intended to secure the communication in the TLS channel. To make the connection more secure, you can also install the root certificate of the RADIUS server on the SND Server (⇔ 181). 		
	 Select SECURITY - Authentication. Select TTLS from the Authentication method list. Enter the user name and the password that are used for the configuration of the SND Server on the RADIUS server. Select the settings intended to secure the communication in the TLS channel. To make the connection more secure, you can also install the root certificate of the RADIUS server on the SND Server (⇔ 181). Click Save & Restart to confirm. 		
	 Select SECURITY - Authentication. Select TTLS from the Authentication method list. Enter the user name and the password that are used for the configuration of the SND Server on the RADIUS server. Select the settings intended to secure the communication in the TLS channel. To make the connection more secure, you can also install the root certificate of the RADIUS server on the SND Server (⇔ 181). Click Save & Restart to confirm. 		

Configuring PEAP

- **Benefits and Purpose** Purpose Purpose Purpose Peap (Protected Extensible Authentication Protocol) validates the identity of devices or users before they gain access to network resources. You can configure the SND Server for the PEAP network authentication. This makes sure that the SND Server gets access to protected networks.
- Mode of Operation In the case of PEAP (compare EAP-TTLS, see ⇒ ■86), an encrypted TLS (Transport Layer Security) channel is established between the SND Server and the RADIUS server. Only the RADIUS server authenticates itself on the SND Server using a certificate that was signed by a CA.

The TLS channel is then used to establish another connection that can be protected by means of additional EAP authentication methods (e.g. MSCHAPv2).

The advantage of this procedure is that only the RADIUS server needs a certificate. Therefore no PKI is needed. PEAP uses the advantages of TLS and supports various authentication methods, including user passwords and one-time passwords.

Requirements If the SND Server is defined as user (with user name and password) on a RADIUS server.

醇 Proceed as follows:

- 1. Start the mySND Control Center.
- 2. Select SECURITY Authentication.
- 3. Select PEAP from the Authentication method list.
- 4. Enter the user name and the password that are used for the configuration of the SND Server on the RADIUS server.
- 5. Select the settings intended to secure the communication in the TLS channel.
- 6. To make the connection more secure, you can also install the root certificate (⇔
 ^B81) of the RADIUS server on the SND Server.
- 7. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

Configuring EAP-FAST

Benefits and Purpose EAP-FAST (Flexible Authentication via Secure Tunneling) validates the identity of devices or users before they gain access to network resources. You can configure the SND Server for the EAP-FAST network authentication. This makes sure that the SND Server gets access to protected networks.

Mode of Operation EAP-FAST uses (as in the case of EAP-TTLS, see ⇒ ■86) a channel in order to protect the data transfer. The main difference is that EAP-FAST does not require certificates for authentication purposes. (The use of certificates is optional).

PACs (Protected Access Credentials) are used to build the channel. PACs are credentials that comprise up to three components.

- A shared secret key that contains the preshared key between the SND Server and the RADIUS server.
- An opaque part that is provided to the SND Server and presented to the RADIUS server when the SND Server wishes to obtain access to network resources.
- Other information that may be useful to the client. (Optional)

EAP-FAST uses two methods to generate PACs:

- The manual delivery mechanism can be every mechanism that the administrator configures and considers to be safe for the network.
- In the case of the automatic delivery, an encrypted channel is established in order to protect the authentication of the SND Server as well as the delivery of the PACs.

Requirements ✓ The SND Server is defined as user (with user name and password) on a RADIUS server.

- 醇 Proceed as follows:
- 1. Start the mySND Control Center.

- 2. Select SECURITY Authentication.
- 3. Select FAST from the Authentication method list.
- 4. Enter the user name and the password that are used for the configuration of the SND Server on the RADIUS server.
- 5. Select the settings intended to secure the communication in the channel.
- 6. Click Save & Restart to confirm.
- \clubsuit The settings will be saved.

8 Maintenance

A number of maintenance activities can be carried out on the SND Server. This chapter contains information on securing and resetting the parameter values. You will also learn how to carry out a restart and a device update.

What information do you need?

- 'How to Secure the SND Parameters (Backup)' ⇔
 [●]91
- 'How to Reset the SND Parameters to their Default Values'
 ⇒
 ^B93
- 'How to Perform an Update' ⇒ 🖹 96

8.1 How to Secure the SND Parameters (Backup)

All parameter values of the SND Server (exception: passwords) are saved in the ' <default name>_parameters' file.

You can save the parameters file as backup copy on your local client. This allows you to get back to a stable configuration status at any time.

You can edit the parameter values of the copied file using a text editor. Afterwards, the configured file can be downloaded to one or more SND Server. The parameter values included in the file will be taken over by the device.

What do you want to do?

- □ 'Displaying Parameter Values' ⇔
 [●]92
- \Box 'Saving the Parameter File' \Rightarrow \bigcirc 92
- \square 'Loading the Parameter File to the SND Server' \rightleftharpoons \blacksquare 92

Displaying Parameter Values

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select MAINTENANCE Parameter backup.
- 3. Click the icon \mathbf{Q} .
- The current parameter values are displayed.

A detailed description of the parameters can be found in the 'Parameter List' \Rightarrow 102.

Saving the Parameter File

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select MAINTENANCE Parameter backup.
- 3. Click the icon \clubsuit .
- 4. Save the '<default name>_parameters.txt' file on a local system with the help of your browser.
- The parameter file is copied and secured.

Loading the Parameter File to the SND Server

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select MAINTENANCE Parameter backup.
- 3. Click Browse.
- 4. Specify the '<default name>_parameter.txt' file.
- 5. Click Import.
- The parameter values in the file are applied to the SND Server.

	8.2 How to Reset the SND Parameters to their Default Values
	It is possible to reset the parameters of the SND Server to the default values (factory settings). All previously configured parameter values will be deleted in this process. Installed certificates will not be deleted.
	Resetting the SND Server may result in a change in the IP address and a loss of the connection to the mySND File Browser and the mySND Control Center.
When is Resetting Recommended?	You must reset the parameters, for example, if you have changed the location of the SND Server and if you want to use it in a different network. Before this change of location, you should reset the parameters to the default settings to install the SND Server in another network.
What do you want to do?	□ 'Resetting the Parameters via the mySND Control Center' \Rightarrow \bigcirc 93
	\square 'Resetting Parameters via the InterCon-NetTool' \Rightarrow \square 94
	\square 'Resetting the Parameters via the Reset Button' \Rightarrow
	By means of the reset button of the device you can reset the parameters without entering the password.
	Resetting the Parameters via the mySND Control Center
	📴 Proceed as follows:
	1. Start the mySND Control Center.
	2. Select MAINTENANCE - Default settings.
	3. Click Reset device to default settings.
	4. Confirm the security query by clicking Reset.
	\checkmark The parameters are reset.

Resetting Parameters via the InterCon-NetTool

Proceed as follows:

- 1. Start the InterCon-NetTool.
- 2. Highlight the SND Server in the device list.
- 3. Select Actions Default Settings from the menu bar.
- 4. Click Finish.
- \clubsuit The parameters are reset.

Resetting the Parameters via the Reset Button

LEDs, the reset button and various ports can be found on the SND Server. These components are described in the 'Quick Installation Guide'.


Using the reset button you can reset the SND Server's parameter values to their default setting. The reset process can be divided into two phases:

- During phase 1, the device is forced into the reset mode. During the reset mode, the parameters are reset.
- The second phase describes the restart of the device.

IMPORTANT: The reset mode is indicated by the synchronous blinking of the activity LED (yellow) and the status LED (green) and last for about five intervals.

You must release the reset button within this time frame, otherwise the device switches to the BIOS mode. If this happens, try the reset again.

The phases are described in the following:



[Phase 2] Restart

Switching on the SND Server (establish the power supply).

Switching off the SND Server

(interrupt the power supply).

mySND User Manual

8.3 How to Perform an Update

You can carry out software and firmware updates on the SND Server. Updates allow you to benefit from currently developed features.

What Happens during an Update? In the course of an update, the existing firmware/software will be overwritten and replaced by a new version. The parameter default settings of the device remain unchanged.

When Is an Update Recommended? An update should be undertaken if functions do not work properly and if SEH Computertechnik GmbH has released a new software or firmware version with new functions or bug fixes.

> Check the installed software and firmware version on the SND Server You will find the version number on the mySND Control Center homepage or in the product list in the InterCon-NetTool.

Where Do I Find the
Update Files?Current firmware and software files can be downloaded from the
homepage of SEH Computertechnik GmbH:

http://www.seh-technology.com/services/downloads/mySND.html

Every update file has its own 'readme' file. Take note of the information contained in the 'readme' file.

- Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select MAINTENANCE Update.
- 3. Click Browse.
- 4. Select the update file.
- 5. Click Install.
- The update is executed. The SND Server is restarting.

8.4 How to Restart the SND Server

The SND Server is rebooted automatically after parameter changes or updates. If the SND Server is in an undefined state, the SND Server can also be rebooted manually.

What do you want to do?

 \square 'Restarting the SND Server via the InterCon-NetTool' \Rightarrow 97

Restarting the SND Server via the mySND Control Center

- 📴 Proceed as follows:
- 1. Start the mySND Control Center.
- 2. Select MAINTENANCE Restart.
- 3. Click Restart device.
- 4. Confirm the security query by clicking Restart.
- The SND Server is restarting.

Restarting the SND Server via the InterCon-NetTool

- 彦 Proceed as follows:
- 1. Start the InterCon-NetTool.
- 2. Highlight the SND Server in the device list.
- 3. Select Actions Restart from the menu bar.
- 4. Click Finish.
- The SND Server is restarting.

9 Appendix



The appendix contains a glossary, the parameter list of the SND Server, and the index lists.

What information do you need?

- 'Glossary' ⇔≣99
- 'Parameter List' ⇒ 🖹 102
- 'Troubleshooting' \Rightarrow 119
- 'List of Figures' ⇔≣122
- 'Index' ⇒≣123

9.1 Glossary

The glossary contains information about manufacturer-specific software solutions and terms from the world of network technology.

What information do you need?

Manufacturer-Specific Software Solutions


- 'mySND Control Center' ⇒ 101
- 'mySND File Browser' ⇔≣101
- 'InterCon-NetTool' ⇒ 🖹 101

Network Technology

- 'Hardware Address' ⇒

 ■100
- 'IP Address' ⇔≣101
- 'Host Name' ⇔≣100
- 'Gateway' ⇒≣100
- 'Subnet Mask' ⇔≣101
- 'Default Name' ⇒ 🖹 99


Default Name The default name of the SND Server is made up of the two letters 'IC' and the device number. The device number consists of the last six numbers of its hardware address.



The default name can be found in the mySND Control Center or in the InterCon-NetTool.

Gateway Using a gateway, you can address IP addresses from external networks. If you want to use a gateway, you can configure the relevant parameter in the SND Server via the mySND Control Center.

Hardware Address The SND Server is addressable by means of its world-wide unique hardware address. This address is commonly referred to as the MAC or Ethernet address. The manufacturer has defined this address in the hardware of the device. The address consists of 12 hexadecimal numbers. The first six numbers represent the manufacturer, while the last six numbers identify the individual device.



The hardware address can be found on the housing or in the InterCon-NetTool.

The use of separators within the hardware address depends on the platform. Note the following conventions when entering the hardware address:

Operating system	Representation	Example
Windows	Hyphen	00-c0-eb-00-01-ff
UNIX	Colon or period	00:c0:eb:00:01:ff or 00.c0.eb.00.01.ff

Host Name

The host name is an alias for an IP address. The host name uniquely identifies the SND Server in the network and makes it easier to remember.

InterCon-NetTool The software InterCon-NetTool has been developed by SEH Computertechnik GmbH for the administration of SEH network devices within a predefined network.

IP Address The IP address is the unique address of each node in a network, i.e. an IP address may occur only once on a local network. The system administrator usually assigns the IP address. The address must be saved in the SND Server to make sure that it can be addressed within the network.

- **mySND Control Center** The SND Server can be configured and monitored via the mySND Control Center. The mySND Control Center is stored in the SND Server and can be displayed by means of a browser software (Internet Explorer, Firefox, Safari).
- **mySND File Browser** The mySND File Browser is used to access files and to work with files (download, etc.). The mySND File Browser is stored in the SND Server and can be displayed by means of a browser software (Internet Explorer, Firefox, Safari).
 - **Subnet Mask** With the help of the subnet mask, large networks can be split up into subnetworks. In this case, the user IDs of the IP addresses are assigned to the various subnetworks. By default, the SND Server is configured for the use without subnetworks. If you want to use a subnetwork, you can configure the relevant parameter in the SND Server via the mySND Control Center.

9.2 Parameter List

This section contains an overview of all the parameters of the SND Server. The parameter list provides details about the functions and values of the individual parameters.

What information do you need?

- 'Parameter List IPv4' ⇒ 🖹 103
- 'Parameter List IPv6' ⇒ 🖹 103
- 'Parameter List DNS' ⇒ 🖹 104
- 'Parameter List POP3' ⇒ 🖹 106
- 'Parameter List SMTP' ⇒ 🖹 106
- 'Parameter List Email Limits' ⇔≣108
- 'Parameter List Bonjour' ⇒ 🖹 108
- 'Parameter List Description' ⇒
 109
- 'Parameter List Date/Time' ⇒ 🖹 109
- 'Parameter List Notification' ⇒
 109
- 'Parameter List User Management' ⇒ 🖹 111
- 'Parameter List Media Assignment' ⇔

 ■113
- 'Parameter List File Filters' ⇒ 🖹 113
- 'Parameter List Automatic File Transfer' ⇒ 🖹 114
- 'Parameter List SSL Connections' ⇔
 □115
- 'Parameter List Device Access' ⇔ 🖹 116
- 'Parameter List TCP port access' ⇔≣116

Parameters	Value	Default	Description
ip_dhcp [DHCP]	on/off	on	Enables/disables the DHCP protocol.
ip_bootp [BOOTP]	on/off	on	Enables/disables the BOOTP protocol.
ip_auto [ARP/PING]	on/off	on	Enables/disables the IP address assignment via ARP/PING.
ip_addr [IP address]	valid IP address	169.254. 0.0/16	Defines the IP address of the SND Server.
ip_mask [Subnet mask]	valid IP address	255.255. 0.0	Defines the subnet mask of the SND Server.
ip_gate [Gateway]	valid IP address	0.0.0.0	Defines the gateway address of the SND Server.

Table 12: Parameter List - IPv4

Table 13: Parameter List – IPv6

Parameters	Value	Default	Description
ipv6 [IPv6]	on/off	on	Enables/disables the IPv6 functionality of the SND Server.
ipv6_auto [Automatic configuration]	on/off	on	Enables/disables the automatic assignment of the IPv6 address for the SND Server.
ipv6_addr [IPv6 address]	n:n:n:n:n:n:n		Defines a manually assigned IPv6 Unicast address in the n:n:n:n:n:n:n format for the SND Server. Every 'n' represents the hexadecimal value of one of the eight 16 bit elements of the address. An IPv6 address may be entered or displayed using a shortened version when successive fields contain all zeros (0). In this case, two colons (::) are used.

Parameters	Value	Default	Description
ipv6_gate [Router]	n:n:n:n:n:n:n:n	::	Defines the IPv6 unicast address of the router. The SND Server sends its 'Router Solicitations' (RS) to this router.
ipv6_plen [Prefix length]	0–64 [1-2 characters; 0-9]	64	Defines the length of the subnet prefix for the IPv6 address. Address ranges are indicated by prefixes. The prefix length (number of bits used) is added to the IPv6 address and specified as a decimal number. The decimal number is separated by '/.

Table 14: Parameter List - DNS

Parameters	Value	Default	Description
dns [DNS]	on/off	on	Enables/disables the name resolution via a DNS server.
dns_primary [Primary DNS server]	valid IP address	0.0.0.0	Defines the IP address of the primary DNS server.
dns_secondary [Secondary DNS server]	valid IP address	0.0.0.0	Defines the IP address of the secondary DNS server. The secondary DNS server is used if the primary DNS server is not available.
dns_domain [Domain name (suffix)]	max. 64 characters [., a-z, A-Z, 0-9]	[blank]	Defines the domain name of an existing DNS server.

Table 15: Parameter List - SNMP

Parameters	Value	Default	Description
snmpv1 [SNMPv1]	on/off	on	Enables/disables SNMPv1.

Parameters	Value	Default	Description
snmpv1_ronly [Read-only]	on/off	off	Enables/disables the write protection for the community.
snmpv1_community [Community]	max. 64 characters [a-z, A-Z, 0-9]	public	Defines the name of the SNMP community. The SNMP community is a basic form of access protection in which several participants with the same access rights are grouped together.
snmpv3 [SNMPv3]	on/off	on	Enables/disables SNMPv3.
any_name [User name]	max. 64 characters [a-z, A-Z, 0-9]	anonymo us	Defines the name of the SNMP user group 1.
any_pwd [Password]	8-64 characters [a-z, A-Z, 0-9]	[blank]	Defines the password of the SNMP user group 1.
any_hash [Hash]	md5 sha	md5	Specifies the hash algorithm of the SNMP user group 1.
any_rights [Access rights]	[None] readonly readwrite	readonly	Defines the access rights of the SNMP user group 1.
any_cipher [Encryption]	[None] aes des		Defines the encryption method of the SNMP user group 1.
admin_name [User name]	max. 64 characters [a-z, A-Z, 0-9]	admin	Defines the name of the SNMP user group 2.
admin_pwd [Password]	8-64 characters [a-z, A-Z, 0-9]	administr ator	Defines the password of the SNMP user group 2.
admin_hash [Hash]	md5 sha	md5	Specifies the hash algorithm of the SNMP user group 2.
admin_rights [Access rights]	[None] readonly readwrite	readwrite	Defines the access rights of the SNMP user group 2.
admin_cipher [Encryption]	[None] aes des		Defines the encryption method of the SNMP user group 2.

Parameters	Value	Default	Description
pop3 [POP3]	on/off	off	Enables/disables the POP3 functionality.
pop3_srv [Server name]	max. 128 characters	[blank]	Defines the POP3 server via the IP address or the host name. The host name can only be used if a DNS server was configured beforehand.
pop3_port [Server port]	1–65535 [1-5 characters; 0-9]	110	Defines the port of the POP3 server used by the SND Server for receiving emails. When using SSL/TLS, enter 995 as port number.
pop3_sec [Security]	0 = [no security] 1 = APOP 2 = SSL/TLS	0	Defines the authentication method to be used.
pop3_poll [Check mail every]	1–10080 [1-5 characters; 0-9]	2	Defines the time interval (in minutes) for retrieving emails from the POP3 server.
pop3_limit [Ignore mail exceeding]	0–4096 [1-4 characters; 0-9; 0 = unlimited]	4096	Defines the maximum email size (in Kbyte) to be accepted by the SND Server.
pop3_usr [User name]	max. 128 characters	[blank]	Defines the user name used by the SND Server to log on to the POP3 server.
pop3_pwd [Password]	max. 128 characters	[blank]	Defines the password used by the SND Server to log on to the POP3 server.

Table 16: Parameter List - POP3

Table 17: Parameter List - SMTP

Parameters	Value	Default	Description
smtp_srv [Server name]	max. 128 characters	[blank]	Defines the SMTP server via the IP address or the host name. The host name can only be used if a DNS server was configured beforehand.

Parameters	Value	Default	Description
smtp_port [Server port]	1–65535 [1-5 characters; 0-9]	25	Defines the port number used by the SND Server to send emails to the SMTP server.
smtp_ssl [TLS]	on/off	off	Enables/disables TLS. The security protocol TLS (Transport Layer Security) is used to encrypt the transmission between the SND Server and the SMTP server.
smtp_sender [Sender name]	max. 128 characters	[blank]	Defines the email address used by the SND Server to send emails. Very often the name of the sender and the user name are identical.
smtp_auth [Login]	on/off	off	Enables/disables the SMTP authentication for the login.
smtp_usr [User name]	max. 128 characters	[blank]	Defines the user name used by the SND Server to log on to the SMTP server.
smtp_pwd [Password]	max. 128 characters	[blank]	Defines the password used by the SND Server to log on to the SMTP server.
smtp_sign [Security (S/MIME)]	on/off	off	Enables/disables the encryption and signing of emails via S/MIME. Only emails from the administration and the notification service can be encrypted.
smtp_encrypt [Full encryption] [Signing of emails]	on/off [off = sign, on = encrypt]	off	Defines the signing and encryption of emails.
smtp_attpkey [Attach public key]	on/off	on	Enables/disables the attachment of a public key to an email.

Parameters	Value	Default	Description
autoSndMaxKb [Total file size limit]	100–10000 [3-5 characters; 0-9]	5000	Defines the total size limit (in kB) of the files that are sent via email during the file transfer via the mySND File Browser ($rac{rac} \equiv 64$) and the automatic file transfer ($rac{rac} \equiv 53$). If the defined value is exceeded, the remaining files will be sent in additional emails during the automatic file transfer.
autoSndMaxFiles [Maximum number of files]	1–100 [1-3 characters; 0-9]	10	Defines the maximum number of files that are sent via email during the file transfer via the mySND File Browser $(rightarrow embed{a})$ and the automatic file transfer $(rightarrow embed{a})$ 53). If the defined value is exceeded, the remaining files will be sent in additional emails during the automatic file transfer.

Table 18: Parameter List - Email Limits

Table 19: Parameter List - Bonjour

Parameters	Value	Default	Description
bonjour [Bonjour]	on/off	on	Enables/disables the Bonjour service.
bonjour_name [Bonjour name]	max. 64 characters [a-z, A-Z, 0-9]	[Default Name]	Defines the Bonjour name of the SND Server.

Parameters	Value	Default	Description
sys_name [Host name]	max. 64 characters [a-z, A-Z, 0-9]	[blank]	Defines the host name of the SND Server.
sys_descr [Description]	max. 64 characters [a-z, A-Z, 0-9]	[blank]	Freely definable description (of the SND Server).
sys_contact [Contact person]	max. 64 characters [a-z, A-Z, 0-9]	[blank]	Freely definable description (of the contact person).

Table 20: Parameter List - Description

Table 21: Parameter List - Date/Time

Parameters	Value	Default	Description
ntp [Date/Time]	on/off	on	Enables/disables the use of a time server (SNTP).
ntp_server [Time server]	max. 64 characters [., a-z, A-Z, 0-9]	pool.ntp. org	Defines a time server via the IP address or the host name. The host name can only be used if a DNS server was configured beforehand.
ntp_tzone [Time zone]	UTC, GMT, EST, EDT, CST, CDT, MST, MDT, PST, PDT, etc.	CET/CE ST (EU)	The time zone is used to equalize the difference between the time received over the time server and the local time, including country-specific particularities such as Daylight Saving Time.

Table 22: Parameter List - Notification

Parameters	Value	Default	Description
mailto_1 mailto_2 [Email address]	valid email address [max. 64 characters]	[blank]	Defines the email address of the recipient for notifications.
noti_dev_1 noti_dev_2 [medium connec- ted/disconnected]	on/off	off	Enables/disables the sending of emails after a removable medium was connected to or disconnected from the SND server.

Parameters	Value	Default	Description
noti_pup_1 noti_pup_2 [Restart]	on/off	off	Enables/disables the sending of emails when the SND Server is restarted.
noti_stat_1 noti_stat_2 [Status email]	on/off	off	Enables/disables the periodical sending of a status email to recipient 1 or 2.
notistat_d [Status notification time]	al = daily mo = Monday tu = Tuesday we = Wednesday th = Thursday fr = Friday sa = Saturday su = Sunday	al	Specifies the interval at which a status email is sent.
notistat_h [hh]	1 = 1. hour 2 = 2. hour 3 = 3. hour etc.	0	Specifies the time at which a status email is sent.
notistat_tm [mm]	0 = 00 minutes 1 = 10 minutes 2 = 20 minutes 3 = 30 minutes 4 = 40 minutes 5 = 50 minutes	0	Specifies the time at which a status email is sent.
trapto_1 trapto_2 [Trap target]	valid IP address	0.0.0.0	Defines the SNMP trap address of the recipient for notifications.
trapcommu_1 trapcommu_2 [Trap community]	max. 64 characters [a-z, A-Z, 0-9]	public	Defines the SNMP trap community of the recipient.
trappup [Restart]	on/off	off	Enables/disables the sending of SNMP traps when the SND Server is restarted.
trapdev [medium connec- ted/disconnected]	on/off	off	Enables/disables the sending of SNMP traps after a removable medium was connected to or disconnected from the SND server.

Parameters	Value	Default	Description
user_active_2 ~ user_active_5	on/off	off	Enables/disables the user account. (The administrator account cannot be disabled.)
user_name_2 ~ user_name_5 [User name]	max. 32 characters [a-z, A-Z, 0-9]	[blank]	Defines the name for the user account in order to log on to the SND server. (The name of the administrator account cannot be changed.)
user_pwd_1 ~ user_pwd_5 [Password]	max. 32 characters [a-z, A-Z, 0-9]	user_pw d_1 = admin user_pw d_2 ~ user_pw d_5 = [blank]	Defines the password for the user account in order to log on to the SND server.
user_email_1 ~ user_email_5 [Email address]	valid email address [max. 64 characters]	[blank]	Defines the email address suggestions for the automatic file transfer.
user_rAdm_2 ~ user_rAdm_5 [Administration]	on/off	off	Enables/disables the administrative access to the mySND Control Center. All connected removable media can be displayed. Only system administrators should have access to the mySND Control Center because this is where security-related settings can be configured. (The option cannot be disabled for the administrator account.)

Table 23: Parameter List - User Management

Parameters	Value	Default	Description
user_rWr_1 ~ user_rWr_5 [Renaming/deletin g files]	on/off	user_rWr _1 = on user_rWr _2 ~ user_rWr _5 = off	Enables/disables the feature for renaming and deleting files in the mySND File Browser.
user_rDI_1 ~ user_rDI_5 [Downloading files]	on/off	user_rDI _1 = on user_rDI _2 ~ user_rDI _5 = off	Enables/disables the download feature in the mySND File Browser.
user_rSd_1 ~ user_rSd_5 [Emailing files]	on/off	user_rSd _1 = on user_rSd _2 ~ user_rSd _5 = off	Enables/disables the email feature in the mySND File Browser.
user_rTog_1 ~ user_rTog_5 [Set/clear archive bit]	on/off	user_rTo g_1 = on user_rTo g_2 ~ user_rTo g_5 = off	Enables/disables the archive bit feature in the mySND File Browser.
user_fFilter_1 ~ user_fFilter_5 [File filters]	0-5 [Number of one of the file filters defined on the SND Server: 0 = no files 1 = all files 2 = filter 2 3 = filter 3 4 = filter 4 5 = filter 5]	1	Defines a file filter for the user account. After logging on to the mySND File Browser, only files of the file types defined in the filter will be displayed.

Parameters	Value	Default	Description
sdCardCid_1 ~ sdCardCid_16 [Device ID]	hexadecimal digit [32 characters]	[blank]	Defines the device ID of an SD card for the unique identification on the SND Server and the assignment to the user accounts. The device ID of an SD card connected to the SND Server is shown in the mySND Control Center.
sdCardName_1 ~ sdCardName_16 [Assignment name]	max. 32 characters [a-z, A-Z, 0-9]	[blank]	Freely definable name for the media assignment.
sdCardUList_1 ~ sdCardUList_16 [User]	User account number [1–16; Multiple entries are to be separated by commas]	[blank]	Assigns one or more user accounts to the SD card. Only assigned user accounts can access the SD card in the mySND File Browser. (Exception: Users with administrator privilege can access all removable media on the SND Server.)

Table 24: Parameter List - Media Assignment

Table 25: Parameter List – File Filters

Parameters	Value	Default	Description
fFilter_name_2 ~ fFilter_name_5 [Filter name]	max. 32 characters [a-z, A-Z, 0-9]	[blank]	Freely definable name of the file filter. The name of the file filter 'All files' cannot be changed.
fFilter_2 ~ fFilter_5 [Accessible file types]	max. 64 characters [., a-z, A-Z, 0-9]	[blank]	Defines the file types displayed in the mySND File Browser by their file extension. - Schema: . <extension> - File types without extension will be defined by a dot. - Multiple entries are to be separated by blanks. The file types of the file filter 'All files' cannot be changed.</extension>

Parameters	Value	Default	Description
autoSndPDMedia	on/off	on	Enables/disables the automatic file transfer from USB mass storage devices.
autoSndPDRcp_1 autoSndPDRcp_2 [Recipient 1, Recipient 2]	valid email address [max. 64 characters]	[blank]	Defines the email address of the recipient for the automatic file transfer from USB mass storage devices.
autoSndPDDir [Source folder]	max. 64 characters [/, a-z, A-Z, 0-9]	/ [Root directory]	Defines the folder on USB mass storage devices from which the files will be transferred automatically. The content from subfolders will not be transferred.
autoSndPDExt [File types]	max. 32 characters [., a-z, A-Z, 0-9]	[blank]	Defines the file types that are transferred automatically from USB mass storage devices by their file extension. - Schema: . <extension> - File types without extension will be defined by a dot. - Multiple entries are to be separated by blanks.</extension>
autoSNDPDaBit [Set archive bit]	on/off	on	Marks files that are transferred from USB mass storage devices by an archive bit. Marked files will not be transferred again when the removable medium is reconnected to the SND server. No archive bit can be set with read-only USB mass storage devices.
autoSndSDMedia_1 ~ autoSndSDMedia_16	on/off	on	Enables/disables the automatic file transfer from SD cards with media assignment.
sdCardAutoRcp_1 ~ sdCardAutoRcp_16 [Recipient]	valid email address [max. 64 characters]	[blank]	Defines the email address of the recipient for the automatic file transfer from SD cards with media assignment.

Parameters	Value	Default	Description
autoSndSDDir_1 ~ autoSndSDDir_16 [Source folder]	max. 64 characters [/, a-z, A-Z, 0-9]	/ [Root directory]	Defines the folder on SD cards from which the files will be transferred automatically. <i>The content from subfolders</i> <i>will not be transferred.</i>
autoSndSDExt_1 ~ autoSndSDExt_16 [File types]	max. 32 characters [., a-z, A-Z, 0-9]	[blank]	Defines the file types that are transferred automatically from SD cards. - Schema: . <extension> - File types without extension will be defined by a dot. - Multiple entries are to be separated by blanks.</extension>
autoSndSDaBit_1 ~ autoSndSDaBit_16 [Set archive bit]	on/off	on	Marks files that are transferred from SD cards by an archive bit. <i>Marked files</i> will not be transferred again when the removable medium is reconnected to the SND server. No archive bit can be set with read-only SD cards.

Table 27: Parameter List - SSL Connections

Parameters	Value	Default	Description
security [Encryption]	1–4 [1 characters]	2	Defines the encryption level to be used for SSL/TLS connections. 1 = low (56 bit) 2 = medium (128 bit) 3 = high (128 - 256 bit) 4 = compatible (40 - 256 bit)

Parameters	Value	Default	Description
http_allowed [HTTP/HTTPS]	on/off	on	Defines the permitted type of connection (HTTP/HTTPS) to the mySND File Browser and the mySND Control Center. If HTTPS is exclusively chosen as the connection type [http_allowed = off], the web access to the mySND File Browser and the mySND Control Center is protected via SSL/TLS.
sessKeyTimer [Session timeout]	on/off	on	Enables/disables the termination of inactive sessions after the expiration of the defined session duration.
sessKeyTimeout [Session duration]	120–3600 [3–4 characters; 0-9]	600	Defines the time interval (in seconds) after which a session on the SND server is aborted for security reasons after a period of inactivity.
usbEnable [USB port]	on/off	off	Enables/disables the USB port on the SND Server.

Table 28: Parameter List - Device Access

Table 29: Parameter List - TCP port access

Parameters	Value	Default	Description
protection [Port access control]	on/off	off	Enables/disables the locking of the selected ports.
protection_test [Test mode]	on/off	on	Enables/disables the test mode. The test mode allows you to test the parameters set using the access control. If the test mode is activated, the access protection remains active until the SND Server is rebooted.

Parameters	Value	Default	Description
protection_level [Security level]	protec_tcp protec_all	protec_tcp	Specifies the port types to be locked: - TCP ports - all ports (IP ports)
ip_filter_on_1 ~ ip_filter_on_8 [IP address]	on/off	off	Enables/disables an exception from the port locking.
ip_filter_1 ~ ip_filter_8 [IP address]	valid IP address	[blank]	Defines elements that are excluded from port locking, using the IP address.
hw_filter_on_1 ~ hw_filter_on_8 [MAC address]	on/off	off	Enables/disables an exception from the port locking.
hw_filter_1 ~ hw_filter_8 [MAC address]	valid hardware address	00:00:00: 00:00:00	Defines elements that are excluded from port locking, using the hardware address.

Table 30: Parameter List - Authentication

Parameters	Value	Default	Description
auth_typ [Authentication method]	[None] MD5 TLS TTLS PEAP FAST		Defines the authentication method that is used to identify devices or users in the network.
auth_name [User name]	max. 64 characters [a-z, A-Z, 0-9]	[blank]	Defines the name of the SND Server as saved in the authentication server (RADIUS).
auth_pwd [Password]	max. 64 characters [a-z, A-Z, 0-9]	[blank]	Defines the password of the SND Server as saved in the authentication server (RADIUS).

Parameters	Value	Default	Description
auth_extern [PEAP/EAP-FAST Options]	= none PLABEL0 = PEAPLABEL0 PLABEL1 = PEAPLABEL1 PVER0 = PEAPVER0 PVER1 = PEAPVER1 FPROV1 = FASTPROV1		Defines the kind of external authentication for the EAP authentication methods TTLS, PEAP, and FAST.
auth_intern [Inner Authentication]	= none PAP = PAP CHAP = CHAP MSCHAP2 = MS-CHAPv2 EMD5 = EAP-MD5 ETLS = EAP-TLS		Defines the kind of inner authentication for the EAP authentication methods TTLS, PEAP, and FAST.
auth_ano_name [Anonymous name]	max. 64 characters [a-z, A-Z, 0-9]	[blank]	Defines the anonymous name for the unencrypted part of the EAP authentication methods TTLS, PEAP, and FAST.
auth_wpa_addon [WPA add-on]	max. 255 characters [a-z, A-Z, 0-9]	[blank]	Specifies an optional WPA expansion.

	9.3 Troubleshooting This chapter describes some problems and their solutions.
Problem	 'The SND Server indicates the BIOS mode' ⇔ ■119 'A connection to the mySND Control Center/mySND File Browser cannot be established! ⇔ ■120
	 'The password is no longer available' ⇒ ■121 The SND Server indicates the BIOS mode
Possible Cause	The SND Server switches to the BIOS mode if the firmware functions well but the software is faulty. This may happen in the case of an incorrect software update, for example. The SND Server indicates the BIOS mode if
	 the activity LED (yellow) blinks periodically and the status LED (green) is <u>not</u> active.

The SND Server is not operational in the BIOS mode.

If the SND Server is in the BIOS mode, the filter 'BIOS mode' will be created automatically in the device list of the InterCon-NetTool. The SND Server is displayed within this filter.

File File Actions Installation Search Image:						
		IP Address	Туре	Version	Protocol	NetWare Name
	8	169.254.207.161	mySND-120	1082505.10		ICODD4B0

Fig. 8: InterCon-NetTool – SND Server in BIOS Mode

The software must be reloaded to the SND Server so that the SND Server can switch from the BIOS mode to the normal mode.

- 📴 Gehen Sie wie folgt vor:
- 1. Start the InterCon-NetTool.
- 2. Highlight the SND Server in the device list. You will find the SND Server under the filter 'BIOS mode'.
- 3. Select Installation IP Wizard from the menu bar. The IP Wizard is started.
- 4. Follow the instructions of the wizard in order to assign an IP address to the SND Server. The IP address is saved.
- 5. Carry out a software update on the SND Server; see: $\Rightarrow \square 96$.
- Structure will be saved on the SND Server. The SND Server switches to the normal mode.

A connection to the mySND Control Center/mySND File Browser cannot be established.

Eliminate possible error sources. First of all, check:

- the cabling connections,
- the IP address of the SND Server (⇔

 ■12) as well as
- the proxy settings of your browser.

If you still cannot establish any connection, the following safety mechanisms might be the cause:

- □ The TCP port access control is enabled \Rightarrow 174.
- □ The access is protected via SSL/TLS (HTTPS) \Rightarrow 17.
- □ The cipher suites of the encryption level are not supported by the browser \Rightarrow \triangleq 69.

The password is no longer available

The access to the SND server is controlled by means of user accounts. You will need a user name and a password to get access to the program.

If the password is no longer available, you can reset the parameter values of the SND Server to their default settings to get access \Rightarrow \Rightarrow 33. Previous settings will be deleted.

9.4 List of Figures

Starting the mySND Control Center	18
nterCon-NetTool – Main Dialog	21
Administration via Email - Example 1	24
Administration via Email - Example 2	
nterCon-NetTool - IP Wizard	27
mySND File Browser	59
mySND Control Center - Certificates	77
nterCon-NetTool – SND Server in BIOS Mode1	19

9.5 Index

A

Address Hardware Address 100 IP address 101 MAC Address 100 Admin account 43 Archive bit 53 ARP/PING 15 Assign SD card 48 Authentication 84

B

Backup Data backup 10 Parameters 91 Backup copy Data 10 Parameters 91 Bonjour 36 BOOTP 13 Browser 6

C

CA certificate 76 Certificate 76 create 78 delete 83 display 78 Saving 80 Certificate request 80 Cipher Suite 69

D

Data backup 10 Default certificate 76 Default name 99 Default settings 93 Descriptions 38 Device number 99 DHCP 13 Disclaimer 11 DNS (Domain Name Service) 30 Documentation 7

Ε

EAP 84 EAP-FAST 89 EAP-MD5 85 EAP-TLS 85 EAP-TTLS 86 Email Limits 33 Enable/disable USB port 73 Encryption Level 69

F

File filters assign 43 Configuring 50 File transfer (automatic) 53 Files delete 66 display 60 email 64 rename 65 search 63 sort 62

G

Gateway 100

Η

Hardware Address 100 Host name 100 Hotline 9 HTTP/HTTPS 71

Ī

IEEE 802.1x 84 Improper Use 10 Inactivity 72 Intended Use 10 InterCon-NetTool 20 install 20 IP Wizard 14 Start 20 Structure 21 IP address 101 Saving 12 IPv4 25 IPv6 28

ī

Login 43 multiple 72

Μ

MAC Address 100 Maintenance 91 Media assignment 48 mySND (my Secure Network Device) 6 mySND Control Center 17 Language 19 login 17 Start 17 Structure 19 mySND File Browser 57 delete feature 66 Download 64 File types 60 Language 59 login 58, 59 renaming feature 65 Search feature 63 send email 64 Sort feature 62 Start 58 Structure 59

Ν

Network Settings 25 Notification Service 40 Notification service Email 41 SNMP trap 41 Notifications 40

Ρ

Parameter file 91 Parameter list 102 Parameters default settings 93 display 92 Load 92 Resetting 93 Saving 92 Password 42 PEAP 88 POP3 32 Protection 68 Protocol BOOTP 13 DHCP 13 IPv4 25 IPv6 28 POP3 32 SMTP 32 SNMP 31 SNTP 39 SSL/TLS 69 Purpose 6

R

RADIUS 84 Removable medium 7 format 47 rename 48 Reset 93 Reset button 24, 94 Restart 97 Restrict file access Disable USB port 73 File filters 50 Rights 43 Root certificate 76

S

S/MIME certificate 77 Security 68 Security level 74 Self-signed certificate 76 Session 72 exit 73 Time out 72 Session timeout 72 SMTP 32 SNMP trap 40 SNMPv1 31 SNMPv3 31 SSL/TLS connection 69 Subnet mask 101 Support 9 System Requirements 6

T

TCP port access control 74 TCP/IP 25 Test mode 74 Time of the device 39 Time server 39 Time zone 39 Types of connection 71 define 71

U

Update 96 User account 42 assign file filters 43 enable/disable 43 Rights 43 UTC 39

V

Version Number 96

Z

ZeroConf 13